

Leaf+Bean

3kg Rechargeable Coffee Scale


G0001706

Instruction Manual

Thank you for choosing the Leaf & Bean 3kg Rechargeable Coffee Scale.

To ensure proper operation and to maintain the lifespan of your product, please read these instructions carefully before first use.

Product Overview



1. **TIMER/UNIT button:** Switches between units (g, oz, ml) and coffee timer function
2. **POWER/TARE button:** For power on, power off and reset weight function
3. **Heat-resistant silicone mat**

Important Safety Instructions

Read all the instructions before operating the scale and retain for future use.

- This scale is intended for indoor household use only.
- Children should not use this product unsupervised.
- Do not operate this scale if it has been dropped, or damaged in any manner.

- The scale should always be used on a hard and stable surface, such as a table or benchtop.
- To protect against the risk of fire, electric shock, or personal injury, do not immerse the appliance in water or other liquids.
- Do not place objects on top of the scale when in storage.
- Always ensure the scale is turned OFF after use to conserve battery life.
- This scale is a high precision strain gauge sensor system measuring device. Do not attempt to disassemble it yourself or knock it heavily. Handle the scale carefully to avoid dropping or breaking it while moving.
- This scale uses a lithium battery, no attempts should be made to gain access to the battery. The battery in this scale is not replaceable.

Packaging and Recycling

The materials used for this product's packaging can be reused, recycled and disposed of through specific waste streams.

- **REUSE:** Keep packaging to safely store or transport your appliance, preventing damage.
- **RECYCLE:** Look for recycling symbols on packaging components to identify if they are recyclable. Check with your local authority to find out what materials are accepted for recycling in your area.
- **DISPOSE:** Look for symbols on packaging components and dispose of materials accordingly.

Technical Information

Default unit	g
Unit Measurement	g, oz, ml
Auto-off time	180 seconds of inactivity or after the timer stops
Manual on/off	Long press the power/time button for 2 seconds
Minimum weight	1g
Maximum weight	3kg
Graduation	0.1g, 0.005oz, 0.1ml
Ratings	Lithium-ion rechargeable battery, 3.7V, 300mAh
Input	5V DC, 1A, USB C

Before First Use

- Carefully unpack the scale and check for any damaged or missing parts.
- Make sure to remove all packaging materials, but do not remove any warning or model labels on the scale.
- Wipe the scale with a damp cloth, but do not allow water to enter the scale.

Operating Instructions

Manual Timing Mode

1. Press the POWER/TARE button for 3 seconds to turn on the scale. Press TIMER/UNIT again to start the timer. The timer will cycle from 0 to 99m:59s and will automatically turn off after the time has elapsed.

 → 

2. When in timer mode, press TIMER/UNIT once to stop the timer, and press it again to resume. To exit manual timing mode, press TIMER/UNIT twice.

 → 

Auto Timing Mode


1. Press the POWER/TARE button for 3 seconds to turn on the scale. Press the POWER/TARE button twice to enter auto timing mode. The Auto indicator will light up on the scale to signal that the function is activated.

 → 

2. Place your hand-brewed coffee equipment on the scale for weighing. Once the weight stabilises, the scale will automatically reset to zero.



 → 

→ 

3. Add a small amount of coffee grounds to the equipment and press POWER/TARE to reset the scale to zero.




 → 

4. Pour water into the hand-brewed coffee equipment, and the scale will automatically start the timer.

 → 

5. After removing all weights, the scale will automatically reset to zero and Auto.



6. Press POWER/TARE twice to exit auto timing mode. The scale will automatically turn off after 180 seconds of inactivity.



 → 

Weighing

1. Place the scale on a flat, hard surface and press POWER/TARE for 3 seconds to turn it on.

 → 

2. Place the item you wish to weigh on the scale. The LED display will show the weight. Press POWER/TARE to reset the scale to zero.



 → 

Unit Conversion

1. When the scale is powered on, it will display the unit from the previous use.



2. To switch units, press and hold TIMER/UNIT for 3 seconds to toggle between g/oz/ml.

 → 


→  → 

To Recharge The Scale


1. Plug in the USB cable for charging. The icon below will blink on the display.

 → 

2. Charging typically takes 2–5 hours. Once fully charged, the LED display will read FULL.





3. After charging is complete, unplug the cable, and the LED display will read as below.



Troubleshooting

Refer to this table if the scale malfunctions and displays any error indicators.

Cause	Error Indicator	Solution
Scale is overloaded		Reduce weight of items on scale.
Low battery voltage		Recharge the scale before using again.

Care Instructions

- This scale is not dishwasher safe.
- Place the scale on a hard, flat surface for the most accurate readings.
- Avoid dropping or subjecting the scale to shocks, as this may cause damage.
- Clean the scale with a damp cloth, but ensure no water enters the scale. Do not use abrasive cleaners.
- To extend the life of the scale, keep it out of hot or wet environments.
- Always store the scale flat, not in an upright position.
- Do not submerge the scale in water.
- The scale platform is heat-resistant up to 130°C. To protect the scale from excess heat while weighing hot items, use the included silicone mat.

Our 12-month Guarantee

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable losses or damage. You are also entitled to have the goods repaired if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

We stand by this product and therefore, we offer a 12-month guarantee. The benefits of this guarantee are in addition to any rights and remedies imposed by the Australian Consumer Law. Our guarantee excludes normal wear and tear and instances where care and use instructions have not been followed.

What IsAlbi will do: During this guarantee period, IsAlbi will repair, replace or refund any defective product. If identical product is not available for replacement, a similar product may be offered. IsAlbi asks you to cover the cost of postage/transit if the product needs to be sent back to us for inspection. If IsAlbi deems the product is defective, we will reimburse your postage/transit expenses. IsAlbi will be responsible for the postage/transit of the repaired/replacement product back to you.

What to do: If a fault/defect is identified, cease using the product immediately. To make a claim on this guarantee, take the product, proof of purchase, and full details of the alleged defect to the retailer from whom the product was purchased. If you cannot access the retailer or are unsatisfied with the solution offered by the retailer, contact IsAlbi via the details below.

IsAlbi

87 Chifley Drive, Preston, Victoria 3072

P: +61 (03) 9474 1300

E: enquiries@isalbi.com.au

isalbi.com.au