








ITEM NAME/NOM D'ITEM: NUE DINING CHAIR
ITEM#/NO. ITEM: 704245

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)	(6)				
 x1	 x1	 x1	A  M6x35 x6 B  M6x70 x2 C  M4x40 x4 D  x2 E  Not provided				
(4)		(5)					
 x1	 x1						

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

Do not FULLY TIGHTEN the screws or nuts for any step until all are in place.





II




III


Step III.1



Step III.2




IV




Please use the attached adjustable footglides to level the chair on an uneven surface.

V



VI



For missing part or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico:(866)798-6663
AI-V1-F008-260616