

Ordering information

Table 2. Fit-All™ Fuse Link Ordering Information

Current Rating	Type X	Type SQ	Type KS	Type 200	Type QA	Type K	Type T
0.2	—	02SQ-60	—	—	—	—	—
0.3	—	03SQ-60	—	—	—	—	—
0.33	41033CPS	—	—	—	—	—	—
0.4	—	04SQ-60	—	—	—	—	—
0.5	41050CPS	—	—	—	—	—	—
0.6	—	06SQ-60	—	—	—	—	—
0.7	—	07SQ-60	—	—	—	—	—
0.75	41075	—	—	—	—	—	—
1	41100CPS	10SQ-60	21001	11001	6413-2T	31001	51001CPS
1.25	41125	—	—	—	—	—	—
1.3	—	13SQ-60	—	—	—	—	—
1.4	—	14SQ-60	—	—	—	—	—
1.5	41150	—	—	—	—	—	—
1.6	—	16SQ-60	—	—	—	—	—
2	41200	—	21002	11002	6414-2T	31002CPS	51002
2.1	—	21SQ-60	—	—	—	—	—
2.5	41250CPS	—	—	—	—	—	—
2.75	41275CPS	—	—	—	—	—	—
3	—	—	21003	11003	6415-2T	31003CPS	51003
3.1	—	31SQ-60	—	—	—	—	—
3.5	41350	35SQ-60	—	—	—	—	—
4	41400	—	—	—	—	—	—
4.2	—	42SQ-60	—	—	—	—	—
5	—	—	21005	11005	6416-2T	31005	51005CPS
5.2	—	52SQ-60	—	—	—	—	—
5.5	41550	—	—	—	—	—	—
6	—	—	21006	—	—	31006	51006
6.3	—	63SQ-60	—	—	—	—	—
7	41007CPS	70SQ-60	21007	11007	6417-2T	31007	51007
7.8	—	78SQ-60	—	—	—	—	—
8	—	—	—	11008	6417-8-2T	31008	51008CPS
10	41010CPS	—	21010CPS	11010	6418-2T	31010	51010CPS
10.4	—	104SQ-60	—	—	—	—	—
12	—	—	—	—	—	31012	51012
14	—	140SQ-60	—	—	—	—	—
15	41015CPS	—	21015	11015	6419-2T	31015	51015
20	—	—	21020	11020	6420-2T	31020CPS	51020CPS
21	—	210SQ-60	—	—	—	—	—
25	—	—	21025	11025	6421-2T	31025CPS	51025
30	—	—	21030	11030	6422-2T	31030CPS	51030CPS
32	—	320SQ-60	—	—	—	—	—
40	—	—	21040	11040CPS	6423-2T	31040CPS	51040CPS
46	—	460SQ-60	—	—	—	—	—
50	—	—	21050CPS	11050	6424-2T	31050CPS	51050CPS
60	—	—	—	—	6425-2T	—	—
65	—	—	21065	11065	—	31065CPS	51065CPS
75	—	—	—	11075	6426-2T	—	—
80	—	—	21080CPS	11080	—	31080CPS	51080CPS
85	—	—	—	11085	—	—	—
100	—	—	21100CPS	11100	6427-2T	31100CPS	51100
125	—	—	21125	11125	6428-2T	—	—
140	—	—	—	—	—	31140	51140
150	—	—	21150CPS	11150	6429-2T	—	—
175	—	—	—	11175	6724-2T	—	—
200	—	—	21200CPS	11200	6725-2T	31200	51200

Table 3. Trip-O-Link™ Fuse Link Ordering Information

Current Rating	Type X	Type KS	Type 200	Type QA	Type K	Type T
.33	42033	—	—	—	—	—
.50	42050	—	—	—	—	—
.75	42075	—	—	—	—	—
1.00	42100	22001	12001	6813	32001	52001
1.25	42125	—	—	—	—	—
1.50	42150	—	—	—	—	—
2	42200	22002	12002	6814	32002	52002
2.50	42250	—	—	—	—	—
2.75	42275	—	—	—	—	—
3	—	22003	12003	6815	32003	52003
3.50	42350	—	—	—	—	—
4	42400	—	—	—	—	—
5	—	22005	12005	6816	—	—
5.50	42550	—	—	—	—	—
6	—	—	—	—	32006	52006
7	42007	22007	12007	6817	—	—
8	—	—	—	—	32008	52008
10	42010	22010	12010	6818	32010	52010
12	—	—	—	—	32012	52012
15	42015	22015	12015	6819	32015	52015
20	—	22020	12020	6820	32020	52020
25	—	22025	12025	6821	32025	52025
30	—	22030	12030	7482	32030	52030
40	—	22040	12040	7483	32040	52040
50	—	22050	12050	7484	32050	52050

Notes:

1. Fit-All fuse links listed above have removable button heads. For non-removable button heads add "A" in front of the part number. Exceptions: Non-removable button heads are not available for Types X, SQ, QA links or 125 A, 150 A and 200 A Type 200 links.
2. Fit-All fuse links listed above are all 23" (584 mm) long. For 26" (660 mm) long fuses links add -29, except the SQ links. For SQ links replace -60 with -26.