

Processing Procedure VERSAVALET™ Garment Bag

- A. Polyester hamper bags must be laundered prior to use.
- B. Polyester hamper bags should be laundered separately from other linen to minimize lint accumulation from other products and maximize the economics of the lightweight synthetic fabric.
- C. We recommend the following washing formula. Combination washer/extractors should be loaded at approximately 70% capacity to allow adequate flow of water across surfaces of polyester hamper bags.
- D. Formula: **This formula is only a guideline.** Alterations should be made at the discretion of the Laundry Professional based on specific requirements, supplies, equipment and experience.

	<u>OPERATION</u>	<u>TIME</u>	<u>LEVEL</u>	<u>TEMP.</u>	<u>SUPPLIES/100 LB.</u>
1.	Flush	2 Min.	High	100°F	N/A
2.	Break	7 Min.	Low	140°F	Detergent/Alkali
3.	Suds	5-7 Min.	Low	140°F	Detergent
4.	Rinse	2 Min.	High	120°F	--
5.	Rinse	2 Min.	High	110°F	--
6.	Rinse	2 Min.	High	100°F	--
7.	Sour	5 Min.	Low	90°F	Sour to pH of 6

- E. After washing, tumble dry at an exhaust temperature of 120°F for 15-20 minutes and an appropriate cool down cycle.

For more information on polyester hamper bags use, performance and/or processing, please call 1-800-999-0400 and ask for the Technical Affairs Department.