











# ASSEMBLY INSTRUCTION


## LOVESEAT & CHAISE

<b>A</b> Seat Frame	<b>B</b> Chaise	<b>C</b> Arm
		
1pc	1pc	2pcs
<b>D</b> Leg	<b>E</b> Backrest	<b>F</b> Backrest
		
9pcs	1pc	1pc
<b>G</b> Seat Cushion	<b>H</b> Back Cushion	<b>I</b> Back Cushion
		
2pcs	1pc	2pcs




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1 Put the Seat Frame (A) on a smooth flat surface and please flip over the Seat Frame (A), then take out the Back Cushion (I) & 1pc Arm (C) from the bottom of it.




- 2 Put the Chaise (B) on a smooth flat surface and open it as bellow shown, then take out the Back Cushion (H) & 1pc Arm (C) & Backrest (F) from the inside of it.




- 
- 3** Hook the Seat Frame (A) onto the Backrest (E) properly.




- 
- 4** Hook the Seat Frame (A) & Backrest (E) onto the Arm (C) properly.




**5** Hook the Chaise (B) onto the Backrest (F) properly.




**6** Hook the Chaise (B) & Backrest (F) onto the Arm (C) properly.



- 7** Put the assembled loveseat & chaise on a smooth flat surface and please flip over them, then assemble Leg (D) to Seat Frame (A) & Chaise (B) until the legs are tight.




- 8** Hook up the loveseat with chaise together as below.



**9**

Put the Seat Cushion (G) on Seat Frame (A), then put Back Cushion (H) on Chaise- (B) and put Back Cushion (I) on seat Cushion (G) as below shown.



### Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.