

ASSEMBLY INSTRUCTION

END TABLE WITH FAUX MARBLE TOP







This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

1

Attach Side Panel (B) to Side Frame (A) by Metal Sheet (F), Bolt (D) and Allen Wrench (H). Then attach Leveler (G) to Side Frame (A) and Side Panel (B) as shown.



Attach assembled metal base to Wood Top (C) by Bolt (E) and Allen Wrench (H) as shown.





Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTION

COCKTAIL TABLE WITH FAUX MARBLE TOP






This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

*** Do not tighten screws & bolts until the entire unit is completely assembled.


1

Attach Side Panel (B) to Side Frame (A) by Metal Sheet (F), Bolt (D) and Allen Wrench (H). Then attach Leveler (G) to Side Frame (A) and Side Panel (B) as shown.



2

Attach assembled metal base to Wood Top (C) by Bolt (E) and Allen Wrench (H) as shown.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.