




Control Overview



Turn the dial button to adjust volume and the navigate the menus.




Press the dial button to access the Main menu and to confirm selections.



Press and hold the dial button to access the Settings menu.

Mute system




Press the dial button to access main menu, navigate to MUTE and press again to mute the audio system.

Select Audio Source



Press the dial button to access main menu, navigate to INPUT and press again to select.




Turn the dial button to select the desired audio source and press to confirm selection.

Select Zone




Press the dial button to access main menu, navigate to ZONE and press again to select.




Turn the dial button to select the desired zone you want to edit and press to confirm selection.

Adjust Visual Appearance



Press and hold the dial button to access Settings menu, navigate to Visuals and press again to select.



Turn the dial button to select the appearance you want to edit and press to confirm selection.

Available Visual Options

Color Scheme

Choose between four display colors to match your decor

Backlight

Control screen brightness for different lighting conditions

Button Light

Adjust the halo light intensity around the dial