# ASSEMBLY AND INSTALLATION INSTRUCTIONS

PD35459BN / **PD35459RBZ / PD35459A**

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. Read and save these instructions.

Hardware Package (included):

Mounting Strap Unit (A)   Mounting Screw (B)   Wire Connector (C)

Canopy (D)   Quick Link (E)   Chain (F)   Collar (G)

Hex Nut (H)   Threaded Pipe-2 (I)   Cap (J)   Finial (K)

Outlet Box
Housing Ground Wire
Wire Connector (C)
Hex Nut
Fixture Wire
Washer
Fixture Ground Wire
Mounting Strap Unit (A)
Green Ground Screw
Mounting Screw (B)
Threaded Pipe
Collar (G)
Canopy (D)
Top Loop
Quick Link (E)
Chain (F)
Loop
Stem
Fixture
Max. 60W Candelabra Bulb (not included)
Candle Cover
Socket
Couple
Hex Nut (H)
Threaded Pipe-2 (I)
Cap (J)
Finial (K)

Installation Steps

Turn off the power at fuse or circuit box.

1. Attach the mounting strap unit (A) to the outlet box by using two mounting screws (B).

2. Attach the loop together with the stem.

3. Choose the length of the chain (F) you need, then weave the fixture wire and the fixture ground wire through the chain (F) , collar (G) and canopy (D).

4. Connect the chain (F) to the loop and the top loop on mounting strap unit (A) with two quick links (E).

5. Thread the fixture wire and fixture ground wire through the top loop, threaded pipe of the mounting strap unit (A).

6. Pull out the source wires from the outlet box.
   Make wire connections using wire connector (C) as follows:
     ---Connect the smooth-coated wire (marked) from the fixture to the black wire from the power source.
     ---Connect the ribbed-coated wire (unmarked) from the fixture to the white wire from the power source.
     ---Attach the fixture grounding wire to the mounting strap unit (A) with the green ground screw . Then connect it to the house ground wire with a wire connector (C) .
   Carefully put the wires back into the outlet box.

VAXCEL

230410

7. Attach the canopy (D) to the mounting strap unit (A) by inserting the top loop, then tighten the collar (G) to secure it.

8. Screw threaded pipe-2 (I) into the couple, and secure it with a hex nut (H). Then attach the cap (J) upward to the fixture, secure it with the finial (K).

9. Attach the candle covers to the sockets.

10. Install 3 x 60W Max. candelabra bulbs (not included). Check relamping label at socket area or packaging for maximum wattage allowed.

Turn on the power at fuse or circuit box.

The following parts are available for reorder if damaged or missing.

Spare Parts List:

Mounting Strap Unit (A)   Mounting Screw (B)   Wire Connector (C)

Canopy (D)   Quick Link (E)   Chain (F)   Collar (G)

Assembly Kit
6319MM (1 SET) for PD35459BN
6318MM (1 SET) for PD35459RBZ
6687MM (1 SET) for PD35459A

Hex Nut (H)   Threaded Pipe-2 (I)   Cap (J)   Finial (K)

Assembly Kit
6688MM (1 SET) for PD35459BN
6689MM (1 SET) for PD35459RBZ
6690MM (1 SET) for PD35459A

A: 24"
B: 11-1/4"

1 Year Warranty

Vaxcel warrants all of our products against defects in workmanship and finishes for one year following the date of shipment.

Exclusions: This warranty does not include the failure of products from extreme acts of nature; environmental conditions not suited for the products intended use; operation in temperatures outside of the range specified in the instruction manual; usage with improper power supply, power surges or dips. For coastal locations, some corrosion is considered normal for the environment.

Vaxcel reserves the right to repair, replace or issue a credit for any properly installed product, provided it is returned per RMA instruction. This warranty is limited to the cost of the product only and does not extend to transportation, installation or replacement costs.

How can warranty service be obtained?
info@vaxcel.com
1-800-482-9235

VAXCEL
230410