





zuo®

ITEM NAME/NOM D'ITEM: AREMI DESK


ITEM# /NO. ITEM: 111325

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)
		
x1	x2	x1
		(4)
		
		x1
A.  x2 JCBC M6 X 60mm	D.  x1 ALLEN KEY M4	G.  x6 JCBB M8 X 35
B.  x2 WOOD BUTTON	E.  x2 SPRING WASHER M6 X12MM	H.  x21 CSK SCREW M4 X32MM
C.  x1 ALLEN KEY M5	F.  x6 SPRING WASHER M6 X16MM	I.  x4 NAIL GLIDE

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

I




II




Usefull tips : assemble the furniture on the packing carton to prevent scratches.

III



IV



For missing parts or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico:(866)798-6663

AI-V1-J012-260721