

BW14726

Salter Alto 24Cm Stockpot - Grs

Please retain instructions for future reference.

CARE AND USE

Not suitable for deep fat frying.

10 YEAR GUARANTEE*

Please retain instructions for future reference.

Before first use thoroughly using the cookware suitable for use on hobs only, including induction, clean the cookware in warm soapy water and dry thoroughly.

Always ensure the cookware is dry prior to use; the excess moisture can lead to staining of the underside.

If cleaning by hand, then ensure to soak for a few minutes in warm soapy water before cleaning. Do not use harsh scouring pad or steel wool.

If the handle becomes loose, simply use a screwdriver to tighten, do not over tighten as this can damage the cookware.

To increase the longevity of the cookware, allow to cool fully before cleaning, place the cookware in the sink, fill with warm soapy water and allow to soak for a few minutes then wash with a soft sponge, rinse and dry thoroughly.

Do not store cookware for prolonged periods of time on the hob/stove (for example leaving a large pan on the stove that isn't being used for 3 days).

Do not leave the cookware on the hob/stove for long periods on high heat.

It is recommended to use a hob/stove size appropriate to the cookware being used.

Never allow cookware to boil dry.

When removing hot cookware from the stove, always use heat-resistant oven gloves to move the cookware.

Never expose hot cookware to cold liquid, it may evidence of damage to the cookware, dispose of it carefully.

Made in China

Manufactured by: UP Global Sourcing UK Ltd, Victoria Street, Oldham, Manchester OL9 0DD. UK
Ultimate Products Europe Ltd, 19 Baggot Street Lower, Dublin, D02 X658. ROI