


ASSEMBLY INSTRUCTION









These pages list all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

How to Use the Ratchet Tool (V)


1. Before assembling the furniture, please adjust the lock as needed.





- 2. Tighten or loosen bolts.
- **Tighten bolts:** Locate the turncap and rotate it clockwise to screw the bolt quickly until it cannot be rotated any more. Then start rotating the handle clockwise to finalize tightening the bolt.




• Loosen bolts: Rotate the handle counterclockwise to loosen the bolt. Then continue rotating the turncap in the same direction to remove the bolt completely.

















Attach Side Cross Bar (J) and Center Cross Bar (G) to Side Rail (E & F) using Bolt (Q) with Ratchet Tool (V).











Attach Support Leg (I) to Center Rail (K) using Bolt (Q) with Ratchet Tool (V). Then attach Center Support Leg (H) and Bracket (N) to Center Cross Bar (G) using Bolt (S) and Nut (T) with Ratchet Tool (V) and Wrench (W).



Insert Slat (L) into Side Rail (E & F) as shown. Then lock Slat Connector (M) to fix Slat (L).



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.