


ASSEMBLY INSTRUCTION


COLLAPSIBLE ACCENT CHAIR

A Chair Frame




1PC

B Chair Cover




1PC




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

1 Unfold the Chair Frame (A)



2 Attach the Chair Cover (B) to the four corners of the Chair Frame (A) and take the back section at the top into account



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

Notes:

- Do not expose wood and leather to direct sunlight or water.
- Periodically moisturize the leather.