




bestchoiceproducts



INSTRUCTION MANUAL

7-Piece Wicker Bar Dining Set



bestchoiceproducts

Thank you for choosing us! Since 2002, Best Choice Products has been bringing customers high-quality products at the absolute lowest price. With everything ranging from instruments and toys to furniture and outdoor, we've got your everyday living essentials covered. We're centered around a customer-first philosophy - with free shipping, exceptional customer service, and a catalog sourced with you in mind.

NOTICE

Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not firmly tighten the screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

TOOLS REQUIRED



305 LBS
PER CHAIR
CAPACITY



130 LBS
TABLE
CAPACITY



1 PERSON
ASSEMBLY




APPROXIMATELY
45 MIN.
ASSEMBLY

HARDWARE

1

M6x50mm
BOLT



12 PCS

2

M6x30mm
SCREW



40 PCS

3

M6x18mm
SCREW



48 PCS

4

M6x12mm
WASHER



116 PCS

5

M6 NUT




16 PCS

PARTS

A


TABLETOP



1 PC

B


TABLE LEG



2 PCS

C


TABLE SUPPORT



1 PC

D


GLASS



2 PCS

E


SEAT



6 PCS

F


CHAIR LEG



12 PCS

G


CHAIR SUPPORT



12 PCS

H

CUSHION




6 PCS

PRODUCT ASSEMBLY


1

Attach two part B table legs to the part A tabletop with twelve part 1 bolts, twenty-four part 4 washers, and twelve part 5 nuts.



2


Attach the part C table support with four part 2 screws, eight part 4 washers, and four part 5 nuts.



PRODUCT ASSEMBLY


3

Place two part D glass pieces on the table.



4


Attach two part F chair legs to the part E seat with six part 2 screws and six part 4 washers, three screws/washers per leg.



PRODUCT ASSEMBLY


5

Attach two part G chair supports with eight part 3 screws and eight part 4 washers, four screws/washers per support.



6

Place a part H cushion onto the chair and secure it with the adhesive strap. Repeat steps 4 to 6 to build the additional chairs.





HELP CENTER



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.