

# MODEL 950DA

## Double Check Detector Assemblies

### 2 1/2" to 10"



#### REPAIR KITS

<b>RK212-950DA</b> REPAIR KIT MODEL 950DA 2-1/2" & 3" RUBBER Only		<b>RK8-950DA</b> REPAIR KIT Model 950DA 8" RUBBER Only	
INCLUDES	DESCRIPTION	INCLUDES	DESCRIPTION
RK34-950XLR	REPAIR KIT for MODEL 950/975, 3/4"	RK34-950XLR	REPAIR KIT for MODEL 950/975, 3/4"
RK212-950	REPAIR KIT for MODEL 950/975, 2 1/2" & 3"	RK8-950	REPAIR KIT for MODEL 950/975, 8"
<b>RK4-950DA</b> REPAIR KIT MODEL 950DA 4" RUBBER Only		<b>RK10-950DA</b> REPAIR KIT Model 950DA 10" RUBBER Only	
INCLUDES	DESCRIPTION	INCLUDES	DESCRIPTION
RK34-950XLR	REPAIR KIT for MODEL 950/975, 3/4"	RK34-950XLR	REPAIR KIT for MODEL 950/975, 3/4"
RK4-950	REPAIR KIT for MODEL 950/975, 4"	RK10-950	REPAIR KIT for MODEL 950/975, 10"
<b>RK6-950DA</b> REPAIR KIT MODEL 950DA 6" RUBBER Only			
INCLUDES	DESCRIPTION		
RK34-950XLR	REPAIR KIT for MODEL 950/975, 3/4"		
RK6-950	REPAIR KIT for MODEL 950/975, 6"		

# MODEL 975DA

## Reduced Pressure

### Detector Assemblies 2 1/2" to 10"

#### REPAIR KITS

<b>RK212-975DA</b> REPAIR KIT MODEL 975DA 2 1/2" & 3" CHECKS Only		<b>RK212-975DAC</b> REPAIR KIT MODEL 975DA 2 1/2" & 3" CHECKS & RELIEF VALVES	
INCLUDES	DESCRIPTION	INCLUDES	DESCRIPTION
RK34-950R	REPAIR KIT for MODEL 950/975, 3/4"	RK34-975R	REPAIR KIT for MODEL 975, 3/4"
RK212-950	REPAIR KIT for MODEL 950/975, 2 1/2" & 3"	RK212-950	REPAIR KIT for MODEL 950/975, 2 1/2" & 3"
		RK212-975R	REPAIR KIT for MODEL 975 REL. VALVE 2 1/2" & 3"
<b>RK4-975DA</b> REPAIR KIT MODEL 975DA 4" CHECKS Only		<b>RK4-975DAC</b> REPAIR KIT MODEL 975DA 4" CHECKS & RELIEF VALVES	
INCLUDES	DESCRIPTION	INCLUDES	DESCRIPTION
RK34-950R	REPAIR KIT for MODEL 950/975, 3/4"	RK34-975R	REPAIR KIT for MODEL 975, 3/4"
RK4-950	REPAIR KIT for MODEL 950/975, 4"	RK4-950	REPAIR KIT for MODEL 950/975, 4"
		RK212-975R	REPAIR KIT for MODEL 975 RELIEF VALVE 4"
<b>RK6-975DA</b> REPAIR KIT MODEL 975DA 6" CHECKS Only		<b>RK6-975DAC</b> REPAIR KIT MODEL 975DA 6" CHECKS & RELIEF VALVES	
INCLUDES	DESCRIPTION	INCLUDES	DESCRIPTION
RK34-950R	REPAIR KIT for MODEL 950/975, 3/4"	RK34-975R	REPAIR KIT for MODEL 975, 3/4"
RK6-950	REPAIR KIT for MODEL 950/975, 6"	RK6-950	REPAIR KIT for MODEL 950/975, 6"
		RK212-975R	REPAIR KIT for MODEL 975 RELIEF VALVE 6"
<b>RK8-975DA</b> REPAIR KIT MODEL 975DA 8" CHECKS Only		<b>RK8-975DAC</b> REPAIR KIT MODEL 975DA 8" CHECKS & RELIEF VALVES	
INCLUDES	DESCRIPTION	INCLUDES	DESCRIPTION
RK34-950R	REPAIR KIT for MODEL 950/975, 3/4"	RK34-975R	REPAIR KIT for MODEL 975, 3/4"
RK8-950	REPAIR KIT for MODEL 950/975, 8"	RK8-950	REPAIR KIT for MODEL 950/975, 8"
		RK8-975R	REPAIR KIT for MODEL 975 RELIEF VALVE 8"
<b>RK10-975DA</b> REPAIR KIT MODEL 975DA 10" CHECKS Only		<b>RK10-975DAC</b> REPAIR KIT MODEL 975DA 10" CHECKS & RELIEF VALVES	
INCLUDES	DESCRIPTION	INCLUDES	DESCRIPTION
RK34-950R	REPAIR KIT for MODEL 950/975, 3/4"	RK34-975R	REPAIR KIT for MODEL 975, 3/4"
RK10-950	REPAIR KIT for MODEL 950/975, 10"	RK8-975R	REPAIR KIT for MODEL 975 RELIEF VALVE 10"
		RK10-950	REPAIR KIT for MODEL 950/975, 10"