



Congratulations on the purchase of your new DMI Sports Table hockey table. Our products are designed and manufactured to give you years of game playing enjoyment.

☒ *KEEP BOX AND PACKING MATERIAL UNTIL TABLE HAS BEEN COMPLETELY ASSEMBLED.*

☒ *ALL DAMAGE MUST BE REPORTED TO DMI WITHIN TEN DAYS OF RECEIPT.*

☒ *If you have any problems with your new product,*

PLEASE DO NOT RETURN IT TO THE STORE.

Please contact us:

1.800.399.4402

FAX: 215.283.9573

Please have your model number when inquiring about parts.

Or write to:

DMI Sports

Customer Service

1300 Virginia Drive, Suite 401

Ft. Washington, PA 19034

Please visit our web site at:

www.dmisports.com

When contacting DMI Sports, please provide your model number and item number (if applicable) if requesting a replacement part. Item numbers can be found inside this owners manual.

Your Model Number **HT280**


Your model number is also located on the original carton. These instructions are also available online at: www.dmisports.com.

IMPORTANT!

Please Keep Your Instructions! (You will need your Model number should you need to contact us.) Before attempting assembly, please read through this instruction book to familiarize yourself with all the parts and assembly steps. We recommend that two adults assemble this table. Please refer to the Parts Identifier on the following page and be sure that all parts have been included. Although extremely rare, occasionally a part may be missing. If you are missing a part, or if you have any questions, please call our customer service department at 1.800.399.4402 Mon-Fri between the hours of 9:00am and 5:00pm E.S.T; or you can reach us at: www.dmisports.com.

Do not return the game to the store. Please contact us first at: 1.800.399.4402 or on our website at: www.dmisports.com.

TWO ADULTS ARE REQUIRED TO ASSEMBLE THIS HOCKEY TABLE







TOOLS REQUIRED FOR ASSEMBLY:



- Allen Wrench-Included
- Wrench-Included
- Level recommended-Not Included

PARTS IDENTIFIER

HARDWARE PARTS








H1	Qty. 12	H2	Qty. 24	H3	Qty. 12	H4	Qty. 4
	3/8" Bolt RPHT280-3/8BOLT		3/8" Washer RPHT280-3/8WASH		3/8" Hex Nut RPHT280-3/8NUT		1" Screw RPHT280-1SCREW
H5	Qty. 8	H6	Qty. 16	H7	Qty. 24	H8	Qty. 16
	2" Screw RPHT280-2SCREW		1/4" Allen Bolt RPHT280-1/4BOLT		1/4" Washer RPHT280-1/4WASH		1/4" Threaded Insert Nut RPHT280-1/4NUT
H9	Qty. 4	H10	Qty. 24	H11	Qty. 8		
	1/2" Screw RPHT280-1/2SCREW		5/8" Screw RPHT280-5/8SCREW		1/4" Bolt RPHT280-1/4BOLT		

ACCESSORY PARTS

A1	Qty. 4	A2	Qty. 4	A3	Qty. 4	A4	Qty. 1
	Pusher RPHT-PUSH		Felt Pad RPHT-FELT		Goal Flex™ Puck RPHT-PUCK		Wrench, Multi RPHT-MWRENCH
A5	Qty. 1						
	1/4" Allen Tool RPHT-1/4TOOL						

PARTS IDENTIFIER

ASSEMBLY PARTS

P1	Qty. 1	P2	Qty. 2	P3	Qty. 2	P4	Qty. 2
 Main Frame RPHT280-FRAME		 Panel, Leg RPHT280-PANEL		 Leg Panel RPHT280-LEGPNL		 Right Leg RPHT280-RLEG	
P5	Qty. 2	P6	Qty. 2	P7	Qty. 2	P8	Qty. 4
 Left Leg RPHT280-LLEG		 Stretcher, Upper RPHT280-UPSTRCH		 Stretcher, Lower RPHT280-LOWSTRC		 Leg Base(Foot) RPHT280-FOOT	
P9	Qty. 4	P10	Qty. 2	P11	Qty. 4	P12	Qty. 2
 Leg Leveler RPHT280-LEV		 Slide Scorer RPHT280-SCORE		 Apron Corner RPHT280-APRCRNR		 Puck Catcher RPHT280-PUCK CATCHER	
P13	Qty. 2	P14	Qty. 1	P15	Qty. 16	P16	Qty. 2
 Blind Post RPHT280-XSUPP2		 Extreme Blind RPHT280-XBLIND2		 .25" X .75" Butterfly Bolt RPHT280-APRONBLT		 End Panel RPHT280-EPANEL	
P17	Qty. 2	P18	Qty. 2	P19	Qty. 2		
 Side Panel RPHT280-SPANEL		 End Rod Cap RPHT280-ENDCAP		 Plastic Insert RPHT280-INSERT			

ASSEMBLY

NOTE: Please leave Main Frame (P1) face down in the carton that it ships in until the legs are attached. All images are shown up-side-down until the table is turned up on its legs.

STEP 1.

To assemble each arched leg, secure Left Leg (P5) to the Right Leg (P4) with Upper Stretcher (P6) and Lower Stretcher (P7) by screwing 1/4" Bolts (H6) and 1/4" Washer (H7) into Threaded Insert Nuts (H8) as shown below. Note: (P7) has a slight curve along the outer edge and is intended to be the bottom support. Do not tighten until you have inserted the curved Leg Panel (P2). Once the Leg Panel has been positioned in place, tighten bolts and washers firmly.





FIG 1.1

STEP 2.

Secure each Leg Base (P8) with 2" Screws (H5). Be sure to secure these Leg bases evenly on both sides of arched leg structure for best appearance. Screw in Leg Levelers (P9).



IMPORTANT

When attaching Leg Base, make sure Leg Leveler (P9) will thread completely through Leg base and slot in leg.

FIG 2.1

ASSEMBLY

STEP 3.

Attach Side and End Aprons (P17 and P16) to each side and end of the table cabinet using Butterfly Bolts (P15) as shown in Figure 3.1. Be sure that the finished side of the aprons are facing out.




FIG.3.1

STEP 4.

Slide each Apron Corner (P11) between the Side and End Aprons (P17 and P16) as shown below in Figure 4.1. Secure Apron Corners (P11) to the Side and End Panels using 5/8" Screw (H10). Secure the puck catchers (P12) onto the ends of the main Frame (P1) using the 1/2" screws (H9).




FIG.4.1

ASSEMBLY

STEP 5.

Set each assembled leg structure between Main Frame (P1) support beams as indicated in Fig. 5.1 and secure tightly with Bolt (H1), Washer (H2) and Hex Nut (H3). Attach the Leg panels (P3) to the Legs (P4 and P5) using the 1/4" Bolt (H11) and 1/4" Washer (H7). DO NOT STAND ON TABLE STRUCTURE TO POSITION LEG ASSEMBLY.





FIG 5.1

STEP 6.

With the assistance of at least one adult, gradually lift and turn your new Hockey Table over. Plug in the blow motor.


Attaching optional Extreme Hockey Blind.

Attach Blind Posts (P13) on each side of the table screw hole. Be sure to attach the blind posts with the tracks facing the table. Carefully the Blind (P14) before inserting the blind in between the two posts. Set it to your desired height. The Extreme blind is removable if traditional play is desired.



STEP 7.

Apply Felt Pads (A2) to the bottom of your Pushers (A1). Congratulations, you're ready to play!



PARTS RE-ORDER FORM**HT280 Table Hockey table**Send this form along with your
check or money order payable to:**DMI SPORTS**

1300 Virginia Drive, Suite 401

Ft. Washington, PA 19034

www.dmisports.com

DATE: _____

NAME: _____

ADDRESS: _____ PHONE: _____

CITY: _____ STATE: _____ ZIP CODE: _____

REF	QTY	PART#	DESCRIPTION	UNIT PRICE	TOTAL AMOUNT
H1		RPHT280-3/8"BOLT	3/8" Bolt (ea.)	.25	
H2		RPHT280-3/8WASH	3/8" Washer (ea.)	.25	
H3		RPHT280-3/8NUT	3/8" Hex Nut (ea.)	.50	
H4		RPHT280-1SCREW	1" Screw (ea.)	.25	
H5		RPHT280-2SCREW	2" Screw (ea.)	.25	
H6		RPHT280-1/4BOLT	1/4" Allen Bolt (ea.)	1.00	
H7		RPHT280-1/4WASH	1/4" Washer (ea.)	.25	
H8		RPHT280-1/4NUT	1/4" Threaded Insert Nut (ea.)	.50	
H9		RPHT280-1/2SCREW	1/2" Screw (ea.)	.25	
H10		RPHT280-5/8SCREW	5/8" Screw (ea.)	.25	
H11		RPHT280-1/4BOLT	1/4" Bolt (ea.)	.25	
P2		RPHT280-PANEL	Panel, Leg (ea.)	15.00	
P3		RPHT280-LEGPNL	Leg panel (ea.)	10.00	
P4		RPHT280-RLEG	Right Leg (ea.)	20.00	
P5		RPHT280-LLEG	Left leg (ea.)	20.00	
P6		RPHT280-UPSTRCH	Stretcher, Upper (ea.)	15.00	
P7		RPHT280-LOWSTRC	Stretcher, Lower (ea.)	15.00	
P8		RPHT280-FOOT	Leg Base (Foot) (ea.)	7.50	
P9		RPHT280-LEV	Leg Leveler (ea.)	4.00	
P10		RPHT280-SCORE	Slide Scorer (ea.)	7.00	
P11		RPHT280-APRCRNR	Apron Corner (ea.)	7.00	
P12		RPHT280-PUCKCATCHER	Puck Catcher (ea.)	3.00	
P13		RPHT280-XSUPP2	Blind Post (ea.)	5.00	
P14		RPHT280-XBLIND2	Extreme Blind (ea.)	25.00	
P15		RPHT280-APRONBLT	.25" x .75 Butter- y Bolt (ea.)	.75	
P16		RPHT280-EPANEL	End Panel (ea.)	10.00	
P17		RPHT280-SPANEL	Side Panel (ea.)	.75	
P18		RPHT280-ENDCAP	End Rod Cap (ea.)	.75	
P19		RPHT280-INSERT	Plastic Insert (ea.)	15.00	
A1		RPHT-PUSH	Pusher (ea.)	2.00	
A2		RPHT-FELT	Felt Pad (ea.)	1.00	
A3		RPHT-PUCK	Puck (ea.)	1.50	
A4		RPHT-MWRENCH	Multi Wrench (ea.)	2.00	
A5		RPHT-1/4TOOL	1/4" Allen Too (ea.)	1.00	

SHIPPING AND HANDLING:**Subtotal:****Up to \$15.00 add \$2.00 for S&H****PA Residents Add 6% State Sales Tax:****Over \$15.00 add \$8.00 for S&H****Shipping and Handling Charges:****Console add \$5.00 for S&H****TOTAL:**