

This Quick Reference Guide provides the necessary information to install a Savant® 2U Rack Shelf (RCK-5000-xx) for use with Savant equipment or third-party equipment.

Box Contents

- (1) RCK-5000-xx Rack Shelf w/ Faceplate (1) Quick Reference Guide (This Document)


Specifications

| Dimensions and Weight | |
|-----------------------|--------------------|
| Height | 3.46 in (8.8 cm) |
| Width | 17.42 in (44.2 cm) |
| Depth | 8.79 in (22.3 cm) |
| Weight (shipping) | 7.0 lb. (3.17 kg) |
| Rack Spaces | 2U |


Rack Shelf Installation

Ventilation for Savant equipment or third-party equipment placed on the rack shelf is provided from the front, rear, bottom, top, and sides of the shelf. Be sure and leave 2". on all sides of devices placed on the shelf to allow for proper airflow around devices.

- 1. Remove the faceplate from the shelf
- 2. Install the shelf in the rack using rack screws (not supplied)
- Line up the faceplate lock pins with the spring clips on the shelf and press 3. into place.



Dimensions



Copyright © 2014 Savant Systems, LLC. SAVANT and RacePoint Blueprint are trademarks of Savant Systems, LLC. All brand names, product names and trademarks are the property of their respective owners. Savant Systems, LLC reserves the right to change product specifications without notice.