6801-402

Sectional


IMPORTANT


homestyles[®]

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.





Cartons 6801-401 and 6801-CUS3 are also needed for assembly.

homestyles Customer Service: www.homestylesfurniture.com, servicedesk@homestylesfurniture.com, 888-680-7460

Assembly Instructions 2/7

IMPORTANT


- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the bolts until each part is properly assembled.
- The unit must be level to work properly. Use the included adjustable levelers to level.
- Keep Hex Wrench as the bolts may need to be tightened in the future.

Follow instructions in 6801-401 carton first, then proceed with Step 13.

Corner Unit STEP 13 Attach Seat (M) to Back (N) with Head Cap Bolts, Μ Spring Washers and Flat Washers, tightening bolts only halfway. Head Cap Bolt Spring Washer Flat Washer Head Cap Bolt Spring Washer Flat Washer **STEP 14** Attach Back (L) to unit with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway. 5

Assembly Instructions 3/7

STEP 15



For a 4 seat sectional, complete Steps 17 and 18.

For a 5 seat sectional, follow instructions in 6801-58 carton, then complete Steps 19 and 20.


For a 6 seat sectional, follow instructions in 2 6801-58 cartons, then complete Steps 21 and 22.

For a 7 seat sectional, follow instructions in 3 6801-58 cartons, then complete Steps 23 and 24.

Assembly Instructions 4/7

4 Seat Sectional

STEP 17



Attach Seat Cushions (F) to unit by pushing toggles through weaving in back of unit. (See Figure 5)

Place Seat Cushion (H) and Back Cushions (I), (K) into position.

Level unit by adjusting the adjustable levelers on bottom of unit. (See Figure 6)





Figure 6

Assembly Instructions 5/7



6801-CUS carton is also needed for this step.

Turn unit to its upright position.

Attach Seat Cushions (F) to unit by pushing toggles through weaving in back of unit. (See Figure 8)

Place Seat Cushion (H) and Back Cushions (I), (K) into position.

Level unit by adjusting the adjustable levelers on bottom of unit. (See Figure 9)





Figure 9

Assembly Instructions 6/7



Two 6801-CUS cartons are also needed for this step.

Turn unit to its upright position.

Attach Seat Cushions (F) to unit by pushing toggles through weaving in back of unit. (See Figure 11)

Place Seat Cushion (H) and Back Cushions (I), (K) into position.

Level unit by adjusting the adjustable levelers on bottom of unit. (See Figure 12)





Figure 12

Assembly Instructions 7/7



Three 6801-CUS cartons are also needed for this step.

Turn unit to its upright position.

Attach Seat Cushions (F) to unit by pushing toggles through weaving in back of unit. (See Figure 14)

Place Seat Cushion (H) and Back Cushions (I), (K) into position.

Level unit by adjusting the adjustable levelers on bottom of unit. (See Figure 15)




Figure 15

CARE INSTRUCTIONS

NEVER

allow liquids to remain on furniture. Absorption causes parts to warp and split and finishes to delaminate.

NEVER

use glass cleaners on finished furniture. Ammonia chemically attacks the finish.



homestyles will provide replacements free of charge for missing or damaged parts within 1 year of purchase. Digital images of the defective parts may be required. If the product was not purchased from an authorized retailer, **home**styles is under no obligation to provide replacement parts. Parts are not available for fully assembled items nor are parts available for sale. Replacements for missing or damaged parts may be requested via contact info below.

homestyles Customer Service: www.homestylesfurniture.com, servicedesk@homestylesfurniture.com, 888-680-7460