

LANGLEY 84W ENTERTAINMENT CONSOLE



ASSEMBLY INSTRUCTIONS




PARTS PACKING CONFIGURATIONS

A. CONSOLE 1 PC	B. LEG 4 PCS	C. SUPPORT LEG 1 PC

FULLY ASSEMBLED




STEP 1:




ASSEMBLY INSTRUCTIONS

STEP 2:



STEP 3:



ASSEMBLY COMPLETE