

# Assembly & Installation Instructions

**CAUTION:** Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

## CHAIN HUNG - CENTER NIPPLE - INDOOR/OUTDOOR

**WARNING** - If any Special Control Devices are used with this Fixture, Follow the Instructions Carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a Qualified Electrical Contractor.

**WARNING** - This product contains chemicals known to the State of California to cause cancer, birth defects and /or other reproductive harm. Thoroughly wash hands after installing, handling, cleaning, or otherwise touching this product.

**CAUTION** - All glass is fragile, use care when handling Glass component(s) and or Lamp(s).


**IMPORTANT NOTICE:**

- This is a generic instruction sheet used for various fixtures.
- Fixture shape and style may vary.
- Glass / Shade / Diffuser shape and style may vary.

**ASSEMBLY STEPS:  
PASOS PARA ENSAMBLAR:  
ÉTAPES D'ASSEMBLAGE**

1. D, E → A
2. F → E
3. R, S, H → G
4. S → H (TO LOCK) (APRETAR) (À VERROUILLER)
5. G → E
6. M → N
7. C → M
8. K → C, M
9. J → C, M
10. L → H
11. C → H, G
12. C → B
13. J, K → H
14. Q → P

A, B, D  
NOT FURNISHED  
NO INCLUIDA  
NON FOURNIE



ADJUST HEIGHT WITH "G"  
R → A (TO LOCK)  
AJUSTA LA ALTURA CON "G"  
R → A (APRETAR)  
RÉGLEZ LA HAUTEUR AVEC "G"  
R → A (À VERROUILLER)

