



HEXO BALLPOINT PEN



- Hexo Ballpoint Pens come equipped with a broad, black ballpoint refill.

1. Remove the front piece (1) from the barrel (2) by turning the barrel (2) counterclockwise.
2. Remove the empty ballpoint refill (4) from the barrel (2).
3. Insert new Faber-Castell Ballpoint Refill (4) into the barrel (2).
4. Return the front piece (1) making sure the spring is centered and the tip of the refill (4) slides into the middle of the spring (4).
5. Secure the front piece (1) by turning the barrel (2) clockwise until fastened.
6. Twist the back piece (3) clockwise to advance the ballpoint (4) and begin writing.
7. To retract the ballpoint (4) twist the back piece (3) counterclockwise.

REFILLS Ballpoint: #148780 Fine, Black
#148789 Medium, Black
#148788 Medium, Blue
#148742 Broad, Black
#148743 Broad, Blue
#148794 Extra Broad, Black
#148793 Extra Broad, Blue