

DAVIS & WADDELL


essentials

Cooking Blowtorch

D2841

www.davisandwaddell.com.au

Thank you for choosing the Davis & Waddell Cooking Blowtorch. To ensure proper operation and to maintain the lifespan of your appliance, please read these instructions carefully before use.



Parts


1. Flame guard
2. Ignition pin
3. Air control collar
4. Adjustment knob
5. Ignition button
6. Filling valve

Important Safety Instructions

Read these instructions carefully and familiarise yourself with the product before lighting or using. Re-read the instructions periodically to refresh your memory. Retain these instructions for future use:

- Use only butane lighter fuel.
- Keep the blowtorch and gas cartridge out of reach of children.
- Do not use an appliance which shows any damage.
- Close the adjustment knob of the appliance before refill.
- Refill the tank in a well-ventilated place, in a flame or ignition source free atmosphere, far from other people. Do not smoke while replacing or refilling.
- Before refilling the device, read the instructions printed on the gas cartridge.
- Always have a fire extinguisher near the blowtorch and work area.
- Disassembling the blowtorch or adding parts may be hazardous.
- Never attempt to modify the blowtorch construction and never use unapproved fuels.
- The blowtorch may not ignite at low or high temperatures due to their effect on the gas pressure.
- Do not perforate or burn the gas cartridges even when they are empty.
- For environmental reasons the gas cartridges should be disposed in specific containers for subsequent recycling.
- Do not work in enclosed spaces, maintain good ventilation.
- Work only in a clean place, far from combustible or greased materials.
- Wear eye protecting equipment.
- Always wear protective gloves and use proper tools to handle hot work.
- Allow the appliance to cool down before storing.

- Do not leave an ignited appliance unattended at any time.
- Avoid breathing in welding/soldering fumes.
- Never try to repair a damaged tool.
- Do not point the flame directly at any person.
- Do not store in temperatures over 40°C.
- Never leave the blowtorch in direct sunlight or in areas where high temperatures are generated.



Do not try to repair or disassemble any parts of the blowtorch

Filling the blowtorch

1. Use only butane fuel.
2. Butane lighter gas can be bought from hardware stores, newsagents, tobacconists and in leading supermarkets. Use the appropriate size valve connector to transfer gas. (Ensure stem and valve are connected)
3. Fill only outdoors or in a ventilated area.
4. Make sure the ON/OFF valve is in the off position (Fig. 4). Turn clockwise until it stops.
5. Turn the unit upside down and insert fill stem into filling valve and press down for 3 to 4 seconds. Repeat three times. Back spray from filling valve indicates that appliance is full (Fig. 1).
6. Do not add attachments to the end of the gas refill canister.

Lighting the blowtorch

1. Turn the ON/OFF knob 2/3 of a turn counter clockwise. Gas will blow out of the burner with a hiss (Fig 2).
2. Push the ignition button. The flame will ignite instantly (Fig 3).
3. If blowtorch does not light then press ignitor button again. If blowtorch still does not light, check and make sure that the air control collar doesn't cover the vent hole. Turn off the ON/OFF valve (Turn ON/OFF valve clockwise until it stops). Hold blowtorch at an angle so that you can see inside the front of the burner. Do not press the ignition pin to the inner face of the burner. With the fuel shut off, press the ignition button, a spark should jump from the ignition pin to the inner face of the burner. Do not press the ignition button with burner pointed toward yourself or anything flammable. If spark jumps, repeat lighting procedure. If the blowtorch still does not light, Try lighting after turning on 1/2 and 3/8 turn.
4. Do not add attachments to the end of the gas refill canister as the valve is designed to accept the gas direct from the gas cartridge without any adaptors added. (These adaptors are only usually provided for cigarette lighters).

Flame adjustment

1. Adjust the blowtorch flame to 1/2 to 1 inch, longer flames only waste fuel.
2. Cooler flames may be achieved by adjusting the air collar until the flame softens. Do not do this while operating as the air control collar gets hot.

Shut down

Turn ON/OFF valve clockwise until it stops. Be sure flame is out and blowtorch is cool before storing blowtorch.

Our 12 Month Guarantee

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

We stand by this product. Therefore we offer a 12 month guarantee on this Electric Ultrasonic Cleaner. The benefits of this guarantee are in addition to any rights and remedies imposed by Australian Consumer Law. Our guarantee excludes normal wear and tear and instances where care and use instructions have not been followed.

What IsAlbi will do: During this guarantee period IsAlbi will repair, replace or refund any defective product. If identical product is not available for replacement, a similar product may be offered. IsAlbi asks you to cover the cost of postage/transit if the product needs to be sent back to us for inspection. If IsAlbi deems the product is defective, we will reimburse your postage/transit expenses. IsAlbi will be responsible for the postage/transit of the repaired/replacement product back to you.

What to do: If a fault/defect is identified cease using the product immediately. To make a claim on this guarantee, take the product, proof of purchase and full details of the alleged defect to the retailer from whom the product was purchased. If you cannot access the retailer or are unsatisfied with the solution offered by the retailer contact IsAlbi via the details below.

IsAlbi

87 Chifley Drive, Preston, Victoria 3072
P: +61 (03) 9474 1300
E: enquiries@isalbi.com.au
isalbi.com.au