

DAVIS & WADDELL

essentials

Atlas Electronic Kitchen Scale

ACC5035

www.davisandwaddell.com.au

Thank you for choosing the Davis & Waddell Atlas Electronic Kitchen Scale. To ensure proper operation and to maintain the lifespan and the optimum accuracy of the scale, please read these instructions carefully before use.

Key Features

- Capacity 5kg/11lbs/176 fl oz
- Graduation 1g/0.1oz/0.03 fl oz
- Liquid measure for water and milk
- Tare function/add & weigh
- Auto off function
- 3 x AAA batteries included

Operation Instructions

- Place scale on a firm, flat surface to use. A kitchen bench is ideal.
- If using a bowl place onto the scale before switching on.
- Press the "On/Off/Tare" key to turn the scale on.
- Press the "Unit" key to select your preferred unit of measurement. Options of weight, milk volume and water volume.
- To change unit of measure, hold down "Unit" key for 3 seconds.
- For the most accurate weight ensure the item being weighed is in the middle of the platform
- Tare lets you reset readout to zero before adding other ingredient to the bowl. A "T" symbol will appear in the top left corner to indicate the Tare function is active.
- If measuring multiple ingredients in

the one bowl press the "On/Off/Tare" key between each new ingredient. This is useful when a recipe requires multiple ingredients to be added to same bowl. Add additional ingredients slowly and carefully while keeping an eye on the readout when using the tare function as if too much of a subsequent ingredient is added, it will be difficult to accurately remove excess weight added to combined ingredients in bowl. A negative weight will appear if the weight is removed when using Tare function.

- If the screen reads "Err" the scale is overloaded. Remove the weight and reset the scale to zero by pressing the "On/Off/Tare" key.
- A negative weight will appear if the weight is removed when using Tare function. Press the "On/Off/Tare" key to clear negative value.
- The scale will power off automatically after at 2 minutes of non-use.

Care

- If the screen reads "Lo" the scales batteries need replacing.
- Wipe the surface of the scale with a damp cloth and dry before and after each use.
- Do not immerse in water and do not use any detergents.
- Do not leave the scale in a damp or steamy environment.
- The scale is for domestic use only and is not legal for trade.
- If the scale is not being used for a long period, please remove the batteries.

Distributed By

IsAlbi

Customer Care

87 Chifley Drive, Preston Vic 3072

P: 03 9474 1300

E: enquiries@isalbi.com.au