

NOTICE

Please retain these instructions for future reference.

- This item is intended for home use only. Do not use this item in a commercial setting.
- This item is not intended for and should be kept out of children.
- This item contains small parts which pose a choking hazard to small children and animals.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This item is designed to be mounted on an existing surface.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not fully tighten screws until the item is completely assembled.
- Assemble only as specified by the following instructions.
- This item is intended for installation into a loadbearing surface; wall studs, anchors, or support beams.

WARNING

- Do not mount this item onto a vehicle.
- Do not overburden or exceed this item's weight capacity.
- Do not place heavy or overburdened storage bins on the top. Store heavy items on the bottom of the peg boards only.
- Do not rest heavy items on this item.
- Do not overtighten this item's screws as this may damage the item's structural integrity.
- Do not attempt to mount this item on a non-loadbearing surface. Locate a stud or cleat to mount this item.

WEIGHT CAPACITY

- Small Bins / 2.2lbs. (each)
- Medium Bins / 3.3lbs. (each)
- Large Bins / 5lbs. (each)
- Overall Bin Capacity / 110lbs
- Additional Tool Wight Capacity / 28lbs

PRODUCT ASSEMBLY

Before installation, please complete the following for maximum product effectiveness:

- Locate existing wall studs and ensure there are no intersecting wires or water pipes.
- Mark the areas to drive your screws using a level to ensure optimum placement.
- Use a power drill to drive pilot holes into the wall stud. This will make inserting the mounting screws easier.
- Use at least 12 screws to mount this item for maximum stability. Use more if necessary.

1. Locate two part A pegboards and orient them so that the storage bin slots are facing upwards. Attach the two boards with your chosen mounting screws to your designated area.

NOTE: It is recommended to check each screw is driven just enough to secure the pegboard. **DO NOT** overtighten the screws.


2. Insert four part C large storage bins into their designated spaces.

NOTE: Place these storage bins into the lower slots of the pegboard only.

3. Insert the sixteen part D small storage bins, and eight part B medium storage bins into your desired space.

4. Insert the remaining part E, F, G, and H tool storage accessories into your desired location on the part A pegboards.

NOTE: Arrange the storage accessories to match your preferred tool layout.



This item does not include any mounting hardware. Please use appropriately sized screws (at least 3-inches long) depending on the wall material. Use longer screws for softer wall materials.



HELP CENTER



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.