

OSLO WALL MOUNT LIGHTING FIXTURES ASSEMBLY/INSTALLATION INSTRUCTIONS

NOTE: Fixtures are suitable for up or down mounting.

- 1. Before beginning the installation, carefully unpack and identify all parts referring to Figure 1. Make sure the supply power is OFF.
- 2. Using 2 JUNCTION BOX SCREWS, securely fasten the CROSSBAR to the JUNCTION BOX.
- 3. <u>MAKE ELECTRICAL CONNECTIONS:</u> (We recommend 2 people for the remainder of installation) Connect the SUPPLY GROUND WIRE to the FIXTURE GROUND WIRE with a wire connector and then secure it to the CROSSBAR with GREEN GROUND SCREW. Using wire connectors, connect the SUPPLY WHITE WIRE to the FIXTURE WHITE (or RIBBED) LEAD; Connect the SUPPLY BLACK (or RED) WIRE to the FIXTURE BLACK (or SMOOTH) LEAD. Wrap all connections with approved electrical tape.
- 4. Place the WALL PLATE over the CROSSBAR; making sure the FIXTURE SCREWS go through the mounting holes on the WALL PLATE. Secure the FIXTURE SCREWS with (2) LOCKING BALLS.
- Place the INNER GLASS SHADE in the OUTER GLASS SHADE carefully. Place over the SOCKET. Thread SOCKET RING onto the end of the SOCKET. Hand-tighten until snug. Repeat for each SHADE.
- Install the LIGHT BULB (sold separately), referring to fixture labels for bulb type and maximum wattage. The bulb quantities depend on the style (See Figure 2).
- 7. Restore supply power (ON). Retain this sheet for future reference.

IF IN DOUBT ABOUT ELECTRICAL INSTALLATION, CONSULT A LICENSED ELECTRICIAN.



