
## WOOD AURORA KITCHEN CART ASSEMBLY INSTRUCTIONS





DO NOT use glass cleaners on furniture as ammonia damages the lacquer.

DO NOT allow any liquids to sit on the wood. This can cause wood to warp and finishes to delaminate.

DO NOT write directly on the surface as it may leave marks.

DO NOT place in direct sunlight, as this may cause fading.

DO NOT use rubber based place mats, as this may cause discoloration. Use cloth place mats.

DO NOT use commercial waxes and polishes, this may cause the finish to yellow.

DO NOT place hot kettles, pans or other high temperature items directly on surface.

Maintain even humidity conditions around your furniture, as this prevents splitting.

Not recommended for use as a cutting board directly. Food should be prepared on an additional surface for safety and to extend the life of the product.

## **Cleaning**

To clean surface, use a soft cloth moistened with lemon oil polish or lukewarm soap and water. Once surface is clean, buff with a dry, clean cloth.