




OWNER'S MANUAL

Table of Contents

Assembly Instruction	01
Installation Guide	02
Operation Instructions	05
Troubleshooting	09
FCC Instruction	10
Customer Service	10

MARGARITAVILLE®












ASSEMBLY INSTRUCTION

ITEM: MV-SS657-LPHL1-403 Sandbar LAF PWR Recliner w/PWR Headrest PWR Lumbar and Audio
 MV-SS657-RPHL1-403 Sandbar RAF PWR Recliner w/PWR Headrest PWR Lumbar and Speaker
 MV-SS657-LCHRH-403 Sandbar LAF Chaise w/Ratchet Headrest and Audio Amp
 MV-SS657-RCHRH-403 Sandbar RAF Chaise w/Ratchet Headrest and Speaker
 MV-SS657-ARH-403 Sandbar Armless Chair w/Ratchet Headrest
 MV-SS657-APHL-403 Sandbar Armless PWR Recliner w/PWR Headrest and PWR Lumbar
 MV-SS657-CRH-403 Sandbar Corner w/Ratchet Headrest and Speaker
 MV-SS657-CS-403 Sandbar Console w/Hidden Cupholders
 MV-SS657-ASLP-403 Sandbar Armless 2 Seat Sleeper w/Ratchet Headrest

Assembly Instruction

Thank you for purchasing this quality product. Please read all instructions carefully before starting the assembly process. Please be sure to unpack carefully as small parts may have come loose during travel from paradise. Helpful tip--do not fully tighten bolts until assembly is complete. It will make assembly easier.

All electronics and components (ONLY LAF Recliner/RAF Recliner/LAF Chaise have)that need to be installed are located in bags under the foundation or attached to the frame. Before discarding the packing materials, ensure that all the parts are accounted for.

No Tools Required For Assembly							
PART LIST							
NO	DESCRIPTION	DRAWING	QUANTITY	NO	DESCRIPTION	DRAWING	QUANTITY
A	LAF Recliner		1	F	Armless Chair		1
B	RAF Recliner		1	G	Armless Recliner		1
C	LAF Chaise		1	H	Wedge		1
D	LAF Recliner/ RAF Recliner /LAF Chaise Wall Plug Transformer		3	I	Console		1
E	RAF Chaise		1	J	Sofa Bed		1



INSTALLATION GUIDE


ITEM: MV-SS657-LPHL1-403 Sandbar LAF PWR Recliner w/PWR Headrest PWR Lumbar and Audio
 MV-SS657-RPHL1-403 Sandbar RAF PWR Recliner w/PWR Headrest PWR Lumbar and Speaker
 MV-SS657-LCHRH-403 Sandbar LAF Chaise w/Ratchet Headrest and Audio Amp
 MV-SS657-RCHRH-403 Sandbar RAF Chaise w/Ratchet Headrest and Speaker
 MV-SS657-ARH-403 Sandbar Armless Chair w/Ratchet Headrest
 MV-SS657-APHL-403 Sandbar Armless PWR Recliner w/PWR Headrest and PWR Lumbar
 MV-SS657-CRH-403 Sandbar Corner w/Ratchet Headrest and Speaker
 MV-SS657-CS-403 Sandbar Console w/Hidden Cupholders
 MV-SS657-ASLP-403 Sandbar Armless 2 Seat Sleeper w/Ratchet Headrest

Installation Guide


Step 1

Connecting power cords and Audio cables with each position according to the corresponding labels depending on your configuration. If you want to move the Console to the RAF side for installation, reverse the left and right audio cable wiring of the Console.

Configuration 1



Configuration 2






INSTALLATION GUIDE

ITEM: MV-SS657-LPHL1-403 Sandbar LAF PWR Recliner w/PWR Headrest PWR Lumbar and Audio
 MV-SS657-RPHL1-403 Sandbar RAF PWR Recliner w/PWR Headrest PWR Lumbar and Speaker
 MV-SS657-LCHRH-403 Sandbar LAF Chaise w/Ratchet Headrest and Audio Amp
 MV-SS657-RCHRH-403 Sandbar RAF Chaise w/Ratchet Headrest and Speaker
 MV-SS657-ARH-403 Sandbar Armless Chair w/Ratchet Headrest
 MV-SS657-APHL-403 Sandbar Armless PWR Recliner w/PWR Headrest and PWR Lumbar
 MV-SS657-CRH-403 Sandbar Corner w/Ratchet Headrest and Speaker
 MV-SS657-CS-403 Sandbar Console w/Hidden Cupholders
 MV-SS657-ASLP-403 Sandbar Armless 2 Seat Sleeper w/Ratchet Headrest


Configuration 3



Step 2

You can connect two or more recliners by connecting each position with male and female buckle. Once completely assembled, your product may look similar to the illustration below, depending on the configuration.

Configuration 1




MARGARITAVILLE®




INSTALLATION GUIDE

ITEM: MV-SS657-LPHL1-403 Sandbar LAF PWR Recliner w/PWR Headrest PWR Lumbar and Audio
 MV-SS657-RPHL1-403 Sandbar RAF PWR Recliner w/PWR Headrest PWR Lumbar and Speaker
 MV-SS657-LCHRH-403 Sandbar LAF Chaise w/Ratchet Headrest and Audio Amp
 MV-SS657-RCHRH-403 Sandbar RAF Chaise w/Ratchet Headrest and Speaker
 MV-SS657-ARH-403 Sandbar Armless Chair w/Ratchet Headrest
 MV-SS657-APHL-403 Sandbar Armless PWR Recliner w/PWR Headrest and PWR Lumbar
 MV-SS657-CRH-403 Sandbar Corner w/Ratchet Headrest and Speaker
 MV-SS657-CS-403 Sandbar Console w/Hidden Cupholders
 MV-SS657-ASLP-403 Sandbar Armless 2 Seat Sleeper w/Ratchet Headrest

Configuration 2




Configuration 3



Step 3

Plug the end cord of transformer into the LAF Recliner/ RAF Recliner/LAF Chaise, Then plug the transformer into a nearby outlet. Make sure the cord doesn't touch the mechanism.






OPERATING INSTRUCTIONS

ITEM: MV-SS657-LPHL1-403 Sandbar LAF PWR Recliner w/PWR Headrest PWR Lumbar and Audio
 MV-SS657-RPHL1-403 Sandbar RAF PWR Recliner w/PWR Headrest PWR Lumbar and Speaker
 MV-SS657-LCHRH-403 Sandbar LAF Chaise w/Ratchet Headrest and Audio Amp
 MV-SS657-RCHRH-403 Sandbar RAF Chaise w/Ratchet Headrest and Speaker
 MV-SS657-ARH-403 Sandbar Armless Chair w/Ratchet Headrest
 MV-SS657-APHL-403 Sandbar Armless PWR Recliner w/PWR Headrest and PWR Lumbar
 MV-SS657-CRH-403 Sandbar Corner w/Ratchet Headrest and Speaker
 MV-SS657-CS-403 Sandbar Console w/Hidden Cupholders
 MV-SS657-ASLP-403 Sandbar Armless 2 Seat Sleeper w/Ratchet Headrest

Operating Instructions




**Caution: Read the important instructions below before operating your power mechanized equipment
 Do not allow children to play on or operate this power mechanized equipment**

Audio Amplifier



AUX input, AUX output are located on the Multimedia Control Box, which can be seen when unzipping the bottom of the LAF Recliner or LAF Chaise. You can connect multiple devices by using a 3.5mm AUX cable connecting the AUX input to the audio source and then connecting another 3.5mm AUX cable from AUX output to the AUX input of the next Multimedia Control Box.

The speakers are at the RAF Recliner/RAF Chaise, Wedge and Armless Chair(As indicated by the arrows), when the device is connected wirelessly, the sound will come out of the speaker.




The bottom is on the side of the side cushion.

MARGARITAVILLE®



OPERATING INSTRUCTIONS

ITEM: MV-SS657-LPHL1-403 Sandbar LAF PWR Recliner w/PWR Headrest PWR Lumbar and Audio
MV-SS657-RPHL1-403 Sandbar RAF PWR Recliner w/PWR Headrest PWR Lumbar and Speaker
MV-SS657-LCHRH-403 Sandbar LAF Chaise w/Ratchet Headrest and Audio Amp
MV-SS657-RCHRH-403 Sandbar RAF Chaise w/Ratchet Headrest and Speaker
MV-SS657-ARH-403 Sandbar Armless Chair w/Ratchet Headrest
MV-SS657-APHL-403 Sandbar Armless PWR Recliner w/PWR Headrest and PWR Lumbar
MV-SS657-CRH-403 Sandbar Corner w/Ratchet Headrest and Speaker
MV-SS657-CS-403 Sandbar Console w/Hidden Cupholders
MV-SS657-ASLP-403 Sandbar Armless 2 Seat Sleeper w/Ratchet Headrest



Care should always be taken to assure there is nothing in the path of the mechanism before and during operation.

To Recline: Sit on the furniture, and press the front of the button closest to the footrest to smoothly raise the footrest and recline to any position, the headrest and lumbar support will be raised when recline the backrest. To lower the footrest and return to an upright position, press the back side of the button closest to the footrest.

To adjust headrest: Press the front of the button closest to the backrest to smoothly raise and adjust the headrest to any position. To lower the headrest and return it to its original position, press the back side of the button closest to the backrest.

To adjust lumbar support: Press the front of the center button to smoothly raise and adjust the lumbar support to any position. To lower the lumbar support and return it to its original position, press the back side of the center button.

To close all: To simultaneously return the headrest, footrest, and lumbar support to their original positions, press and hold the back side of the button closest to the footrest.



OPERATING INSTRUCTIONS


ITEM: MV-SS657-LPHL1-403 Sandbar LAF PWR Recliner w/PWR Headrest PWR Lumbar and Audio
 MV-SS657-RPHL1-403 Sandbar RAF PWR Recliner w/PWR Headrest PWR Lumbar and Speaker
 MV-SS657-LCHRH-403 Sandbar LAF Chaise w/Ratchet Headrest and Audio Amp
 MV-SS657-RCHRH-403 Sandbar RAF Chaise w/Ratchet Headrest and Speaker
 MV-SS657-ARH-403 Sandbar Armless Chair w/Ratchet Headrest
 MV-SS657-APHL-403 Sandbar Armless PWR Recliner w/PWR Headrest and PWR Lumbar
 MV-SS657-CRH-403 Sandbar Corner w/Ratchet Headrest and Speaker
 MV-SS657-CS-403 Sandbar Console w/Hidden Cupholders
 MV-SS657-ASLP-403 Sandbar Armless 2 Seat Sleeper w/Ratchet Headrest

To adjust headrest


Hold the back of the headrest with your hand, push it up wherever you need to adjust it, and let go so that the headrest can adjust to the position you want.

To return the headrest to its original position


Hold the back of the headrest with your hand, push it up to the very top, and let go so that the headrest can return to its original position.




Armless chair




Manual headrest




Wedge




Manual headrest




Sofa bed




Manual headrest




LAF Chaise



Manual headrest



RAF Chaise



Manual headrest





OPERATING INSTRUCTIONS

ITEM: MV-SS657-LPHL1-403 Sandbar LAF PWR Recliner w/PWR Headrest PWR Lumbar and Audio
 MV-SS657-RPHL1-403 Sandbar RAF PWR Recliner w/PWR Headrest PWR Lumbar and Speaker
 MV-SS657-LCHRH-403 Sandbar LAF Chaise w/Ratchet Headrest and Audio Amp
 MV-SS657-RCHRH-403 Sandbar RAF Chaise w/Ratchet Headrest and Speaker
 MV-SS657-ARH-403 Sandbar Armless Chair w/Ratchet Headrest
 MV-SS657-APHL-403 Sandbar Armless PWR Recliner w/PWR Headrest and PWR Lumbar
 MV-SS657-CRH-403 Sandbar Corner w/Ratchet Headrest and Speaker
 MV-SS657-CS-403 Sandbar Console w/Hidden Cupholders
 MV-SS657-ASLP-403 Sandbar Armless 2 Seat Sleeper w/Ratchet Headrest


Storage

Lift the upper part in front of the sofa and there will be a storage space.




2 × Sliding Cup Holders

- ❶ Pull to open the hidden cup holder compartment
- ❷ Push to close the hidden cup holder compartment





Deep & Shallow Storage



USB & Type-C Ports

Sofa Bed

Before use, remove the velcro from the mech at the bottom of the sofa bed.








OPERATING INSTRUCTIONS

ITEM: MV-SS657-LPHL1-403 Sandbar LAF PWR Recliner w/PWR Headrest PWR Lumbar and Audio
 MV-SS657-RPHL1-403 Sandbar RAF PWR Recliner w/PWR Headrest PWR Lumbar and Speaker
 MV-SS657-LCHRH-403 Sandbar LAF Chaise w/Ratchet Headrest and Audio Amp
 MV-SS657-RCHRH-403 Sandbar RAF Chaise w/Ratchet Headrest and Speaker
 MV-SS657-ARH-403 Sandbar Armless Chair w/Ratchet Headrest
 MV-SS657-APHL-403 Sandbar Armless PWR Recliner w/PWR Headrest and PWR Lumbar
 MV-SS657-CRH-403 Sandbar Corner w/Ratchet Headrest and Speaker
 MV-SS657-CS-403 Sandbar Console w/Hidden Cupholders
 MV-SS657-ASLP-403 Sandbar Armless 2 Seat Sleeper w/Ratchet Headrest

How to use your sofa bed

If you want to use sofa bed, first pull the middle strap forward, then pull the strap up, and finally hold the strap on both sides. Pull it down so that you can enjoy your sofa bed.



Troubleshooting

PROBLEM	POSSIBLE FACTORS	SOLUTIONS
The side switch doesn't work.	The backrest or leg rest is in the middle position, or the product cannot be operated while a click sound is heard.	Replace the switch and control box.
Some seats on the sectional have a sound on their horns, others don't, or the vibrators don't vibrate.	The cable connection between the horn and the amplifier is short-circuited.	Please contact the dealer, and you need to gradually troubleshoot the connection line disconnection fault according to the specific product model.
The sectional makes a squeak during opening and closing.	- Friction of the chair frame mechanism. - Leather and fabric rubbing. - The mechanism in the backrest hangs the cloth when it runs. - There is a noticeable whistling sound of the motor. - The frame and the iron frame are not secure; When you sit and shake your body in a resting position, you can still hear a creaking sound.	- Replace the iron frame. - Arrange for a maintenance company to do a sound reduction treatment, or replace the holster. - Ask the maintenance company to open the backrest and adjust the cloth. - Replace the motor. - Arrange for the repair company to repair and tighten the connection between the iron frame and the seat frame.
The sectional stretches or shrinks and stutters.	- The iron frame rests are deformed. - There is an even pause when the backrest or leg rest is opened. It is possible that the motor hall sensor is damaged.	- Replace the iron frame. - Replace the motor.
The power light is not on.	- The AC cable end is not plugged in. - The power cord is not plugged in.	- Select another outlet with normal power supply and plug it into the AC side of the power supply. - Replace the power supply.

MARGARITAVILLE®



OPERATING INSTRUCTIONS

ITEM: MV-SS657-LPHL1-403 Sandbar LAF PWR Recliner w/PWR Headrest PWR Lumbar and Audio
MV-SS657-RPHL1-403 Sandbar RAF PWR Recliner w/PWR Headrest PWR Lumbar and Speaker
MV-SS657-LCHRH-403 Sandbar LAF Chaise w/Ratchet Headrest and Audio Amp
MV-SS657-RCHRH-403 Sandbar RAF Chaise w/Ratchet Headrest and Speaker
MV-SS657-ARH-403 Sandbar Armless Chair w/Ratchet Headrest
MV-SS657-APHL-403 Sandbar Armless PWR Recliner w/PWR Headrest and PWR Lumbar
MV-SS657-CRH-403 Sandbar Corner w/Ratchet Headrest and Speaker
MV-SS657-CS-403 Sandbar Console w/Hidden Cupholders
MV-SS657-ASLP-403 Sandbar Armless 2 Seat Sleeper w/Ratchet Headrest

FCC INSTRUCTION

Caution: Changes or modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Customer Service

If you have any questions regarding the use of this unit, or find that your unit needs service, please contact your retailer.