


**SIGN FRAME KIT CONTAINS:**

- 1 x WW Sign Frame Support Block
- 1 x WW Sign Frame with Plexi Sheet installed
- 1 x Signage as purchased

**STEP-BY-STEP INSTRUCTIONS**

- 1 Locate the WW Sign Frame Support Block
- 2 Take the WW Sign Frame Support Block (tabs facing to the back) and feed into the rim holes located at the back of the Waste Watcher body. *Note - A snap will be heard once Support Block is engaged into body. Support block has now been installed into the Waste Watcher body. **(FIG. 1)**
- 3 From the top of the sign frame, slowly feed your signage into the WW Sign Frame slot until fully inserted. Reverse this process to remove signs to either update or replace. **(FIG. 2)**
- 4 Snap bottom of Waste Watcher Sign Frame into exposed slotted holes in the WW Support Block. *Note - A snap will be heard once Sign Frame has been successfully installed. **(FIG. 3)**

To Remove WW Sign Frame and Support Block:

Locate the Sign Frame tabs at the back of the Support Block, with gently force flex tab away from the bin. Do this step until each of the 2 tabs have disconnected from the Support Block. Support block should still remain engaged to the body. **(FIG. 4)**

To remove Support Block, push exposed tabs towards inside of body and apply a downward pressure to disengage tabs from body. The Support Block can then be removed. **(FIG. 1)**

