










ASSEMBLY INSTRUCTION


COFFEE TABLE

A Glass Top	B Top Frame	C Bottom Glass	D Bottom Frame
			
1pc	1pc	1pc	1pc
E Support Post	F Leg	G Glass Sucker	H Glass Pad
			
4pcs	4pcs	8pcs	8pcs




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1 Put the Top Frame (B) on a smooth flat surface, attach Support Post (E) to Top Frame (B) as below shown.




2 Assemble Bottom Frame (D) with Support Post (E) using Leg (F) as below shown.



-
- 3** Attach Glass Pad (H) on the Top Frame (B), then put the Glass Top (A) onto the Glass Pad (H) as below shown.



-
- 4** Insert Glass Sucker (G) into the holes of Bottom Frame (D), then put the Bottom Glass (C) onto the Glass Sucker (G) as below shown.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.