




bestchoiceproducts



INSTRUCTION MANUAL

Mobile Elevated Wood
Planter with Shelf



bestchoiceproducts

As shoppers, we're always trying to find the perfect balance between quality & value. At BCP, we believe we've achieved that. Our diverse catalog of everyday essentials is tailored especially to our customers & guaranteed to hit that sweet spot of high quality & low price.

— Always. —

! NOTICE

Please retain these instructions for future reference.

- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not firmly tighten the screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

TOOLS REQUIRED



PHILLIPS
SCREWDRIVER



ELECTRIC DRILL
(OPTIONAL)



1 PERSON
ASSEMBLY



APPROXIMATELY
20 MIN.
ASSEMBLY

HARDWARE

1

M4 X 40MM
SCREW



24 PCS

2

M4 X 30MM
SCREW



12 PCS

3

M4 X 45MM
SCREW



8 PCS

4

DOWEL



4 PCS

5

M6 X 80MM
BOLT SET



4 PCS

6

M4 X 25MM
SCREW



56 PCS

7

CASTER



2 PCS

8

LOCKING
CASTER




2 PCS

PARTS

A1


LEG I



2 PCS

A2


LEG II



2 PCS

B


LONG PANEL



2 PCS

C

SHORT PANEL



2 PCS

D

BOTTOM PANEL I



2 PCS

E


BOTTOM PANEL II



2 PCS

F


SUPPORT



3 PCS

G


LEG CAP



4 PCS

H


LINING



1 PC

I


LEG SUPPORT



2 PCS

J

SHELF PANEL




14 PCS

PRODUCT ASSEMBLY

2


Attach two part C short panels to two part A1 and two part A2 legs with twelve part 1 screws, three screws per leg.



PRODUCT ASSEMBLY


2

Attach two part B long panels to a short panel side with six part 1 screws.



3


Slide two part D and two part E bottom panels into the designated slots.



PRODUCT ASSEMBLY


4

Attach the other short panel side with six part 1 screws.



5


Attach three part F supports with twelve part 2 screws.



PRODUCT ASSEMBLY


6

Flip the planter onto its legs. Place the part H lining.



7


Attach four part G leg caps with four part 4 dowels and eight part 3 screws.



PRODUCT ASSEMBLY


8

Attach two part I leg supports with four part 5 bolt sets.



9


Attach fourteen part J shelf panels with fifty-six part 6 screws.



PRODUCT ASSEMBLY

10

Screw in two part 7 casters and two part 8 locking casters.



Earn points while you shop. Join today!

bestchoiceproducts **rewards\$**

Join | Earn | Redeem

Give your friends 15% off their first order! For each successful referral you'll receive 100 points.

bestchoiceproducts.com



HELP CENTER



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.