








# MOBILE STAND EVOLUTION PLUS MECHANICAL

1







INSTRUCTIONS • INSTRUCTIES • ISTRUZIONI • ANLEITUNG • INSTRUCCIONES • INSTRUÇÕES



# MOBILE STAND EVOLUTION PLUS MECHANICAL

2

INSTRUCTIONS • INSTRUCTIES • ISTRUZIONI • ANLEITUNG • INSTRUCCIONES • INSTRUÇÕES



## EN

- a) Warning of danger if incorrectly assembled and/or installed;
- b) Installation only to be carried out by a competent person;
- c) Need to check the suitability of the wall/ceiling and to check that the fastening devices will withstand the forces generated.

## DE

- a) Warnung vor gefahr wenn falsch montiert oder installiert;
- b) Installation nur durch kompetentes fachpersonal;
- c) Eignung der wand feststellen, und nachprüfen ob die befestigungsvorrichtungen den erzeugten kräfte standhalten.

## FR

- a) Risque de danger si montage ou fixation incorrecte;
- b) Mise en place par personne compétente;
- c) Vérification du type de mur ou plafond et utilisation des chevilles et accessoires fixation selon sa nature.

## IT


- a) Attenzione: può essere pericoloso se non correttamente montato o installato;
- b) Installazione da effettuarsi solo tramite personale competente;
- c) Verificare l'idoneità della parete/soffitto e assicurarsi che i dispositivi di fissaggio siano in grado di resistere alla forza generata.

## ES

- a) Aviso de peligro en caso de ensamblaje y/o instalación incorrecta;
- b) La instalación ha de ser realizada exclusivamente por personal competente;
- c) Necesidad de verificar la idoneidad del muro/techo y la resistencia de los dispositivos de cierre a las fuerzas generadas.

## PT

- a) Perigo em caso de instalação ou montagem incorreta;
- b) Instalação para ser feita apenas por pessoa competente;
- c) Necessário verificação se parede/teto é adequada e verificação se os acessórios de fixação suportam as forças a serem geradas.



REV00