

AEROFLY WHEELCHAIR



- | | |
|--|---|
| <p>1. Armpad-
Right- AEROFLY-01
Left- AEROFLY-02</p> <p>2. Back Cushion-
Orange 18"- AEROFLY-03-18
Orange 20"- AEROFLY-03-20
Blue 18"- AEROFLY-04-18
Blue 20"- AEROFLY-04-20
Red 18"- AEROFLY-05-18
Red 20"- AEROFLY-05-20
Grey 18"- AEROFLY-06-18
Grey 20"- AEROFLY-06-20</p> <p>3. Back Upholstery 18"- AEROFLY-07-18
3. Back Upholstery 20"- AEROFLY-07-20</p> <p>4. Brake Cable- AEROFLY-08</p> <p>5. Brake-
Left- AEROFLY-09
Right- AEROFLY-10</p> <p>6. Brake Tip- AEROFLY-11</p> <p>7. Handlebar Assembly-
Left Gray- AEROFLY-12
Left Black- AEROFLY-12BLK
Right Gray- AEROFLY-13
Right Black- AEROFLY-13BLK
Hand Grip- AEROFLY-43</p> <p>8. Handlebar Release- AEROFLY-14</p> <p>9. Rear Wheel- AEROFLY-15</p> <p>10. Handrim & Hardware- AEROFLY-16</p> <p>11. Quick Release axle- AEROFLY-17</p> <p>12. Q/R axle sleeve- AEROFLY-18</p> <p>13. Caster- AEROFLY-19</p> <p>14. Caster Axle- AEROFLY-20</p> <p>15. Caster Bearing- STDS1011</p> <p>16. Clothing Guard-
Left- AEROFLY-21
Right- AEROFLY-22</p> <p>17. Hand Brake Assy- AEROFLY-23</p> <p>18. Seat Upholstery 18"- AEROFLY-24-18
Seat Upholstery 20"- AEROFLY-24-20</p> | <p>19. Seat cushion-
Orange 18"- AEROFLY-25-18
Orange 20"- AEROFLY-25-20
Blue 18"- AEROFLY-26-18
Blue 20"- AEROFLY-26-20
Red 18"- AEROFLY-27-18
Red 20"- AEROFLY-27-20
Grey 18"- AEROFLY-28-18
Grey 20"- AEROFLY-28-20</p> <p>20. Fork Assembly- AEROFLY-29</p> <p>21. Fork Stem Bearing- AEROFLY-30</p> <p>22. Footrest Attachment Block- AEROFLY-31</p> <p>23. Footplate-
Right- AEROFLY-32
Left- AEROFLY-33
Heel Loops (pr)- STDS831</p> <p>24. Cross Frame 18" Gray- AEROFLY-34
Cross Frame 18" Gray- AEROFLY-34N [1]
Cross Frame 18" Black- AEROFLY-34BLK
Cross Frame 18" Black- AEROFLY-34BLKN [1]
Cross Frame 20" Gray- AEROFLY-34-20
Cross Frame 20" Black- AEROFLY-34-20BLK</p> <p>25. Cross Frame Guide Set- AEROFLY-35</p> <p>26. Cross Frame End Cap Set- AEROFLY-36</p> <p>27. Side Frame-
Left 18" Gray- AEROFLY-37
Left 18" Gray- AEROFLY-37N [1]
Left 18" Black- AEROFLY-37BLK
Left 18" Black- AEROFLY-37BLKN [1]
Left 20" Gray- AEROFLY-37-20
Left 20" Black- AEROFLY-37-20BLK
Right 18" Gray- AEROFLY-38
Right 18" Gray- AEROFLY-38N [1]
Right 18" Black- AEROFLY-38BLK
Right 18" Black- AEROFLY-38BLKN [1]
Right 20" Gray- AEROFLY-38-20
Right 20" Black- AEROFLY-38-20BLK</p> <p>28. Frame End Caps (pr)- AEROFLY-39</p> <p>29. Anti-Tippers (pr)- AEROFLY-40
Anti-Tippers Black (pr)- AEROFLY-40BLK</p> <p>30. Footrest (pair)- AEROFLY-42</p> <p>31. Cup Holder Bracket- AEROFLY-41</p> |
|--|---|