








ITEM NAME/NOM D'ITEM: SAKINA SOFA
ITEM#/NO. ITEM: 704258


PARTS LIST/LISTE DES PIÈCES

(1)	(2)	(3)	(8)
 x1	 x1	 x1	 A M6x40 x4 B M6x45 x6 C M6x60 x3 D x2
(4)	(5)	(6)	(7)
 x1	 x1	 x2	 x1


ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

Do not FULLY TIGHTEN the screws or nuts for any step until all are in place.


I




II




III




IV



V





VI



Assembled

Please use the attached adjustable footglides to level the sofa on an uneven surface.





For missing part or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico:(866)798-6663
AI-V1-F008-260616