

INSTALLATION AND SAFETY INSTRUCTIONS

FOR YOUR SAFETY

WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF; EITHER THE FUSE IS REMOVED OR THE CIRCUIT BREAKER IS SHUT OFF.

GENERAL

You don't need special tools to install this fixture. Be sure to follow the steps in the order given. Under no circumstances should a fixture be hung on house electrical wires, nor should a swag type fixture be installed on a ceiling, which contains a radiant type heating system. Read instructions carefully. If you are unclear as to how to proceed, consult a qualified electrician.

NOTE: Proper wiring is essential for the safe operation of this fixture.

FIXTURE ASSEMBLY

Carefully removed the fixture from the carton and check that all parts are included as shown in figure. Be careful not to misplace any of the screws or parts, which are needed to install this fixture.

INSTALLATION

Step 1: Pulling socket rings (I) off of sockets (G) and separate face plate (H) from back plate (A).

Step 2: Unscrew the green grounding screw (D) from the back plate.

Step 3: Position flat side of back plate (A) against wall at mounting location and mark outer holes with a pencil.

Note: back plate must be level for fixture to hang straight.

Step 4: Drill a 5/16" hole at each mark then insert wall anchors by gently tapping with a hammer.

Step 5: Pull out the source wires from the outlet box(not included).

Make wire connections with wire connectors(C) as follows:

--Use the wire connector(C) to connect the white fixture wire to the white (neutral) supply wire from the outlet box (not included).

--Use the wire connector(C) to connect the black fixture wire to the black (live) supply wire from the outlet box (not included).

--Wrap the ground wire from the back plate (A) around the green ground screw (D) on the back plate (A). Connect the ground wire from the back plate (A) to the ground wire from the outlet box (not included), cover the connection with wire connector (C).

Step 6: Secure back plate (A) to wall with wood screws (F) and wall anchors (E) attach the back plate (A) to the outlet box (not included) using the mounting screws (B).

Step 7: Secure the ground wire to the back plate (A) with the green ground screw (D).

Step 8: Position face plate (H) over back plate (A) and sockets (G).

Step 9: Secure by pushing socket rings (I) over sockets (G).

Step 10: Install the bulbs(not included). Don't exceed the maximum capacity recommended on the fixture).

CLEANING

To clean, wipe fixture with a soft and dry cloth. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

Line art shown may not exactly match the fixture enclosed. However, the installations do apply to this fixture.

