



ITEM NAME/NOM D'ITEM: SAKINA CHAISE LOUNGE
ITEM#/NO. ITEM: 704243


PARTS LIST/LISTE DES PIÈCES

(1)	(2)
 x1	 x1

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE


Do not FULLY TIGHTEN the screws or nuts for any step until all are in place.

I




Please use the attached adjustable footglides to level the lounge on an uneven surface.

II




III


Level 1




Level 2



Level 3





For missing part or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico:(866)798-6663
AI-V1-F008-260616