



IND-C208V

Induction Cooker Instruction Manual

This manual contains important information regarding your unit.
Please read this manual thoroughly prior to equipment set-up, operation, and
maintenance. Failure to comply with regular maintenance guidelines outlined in this
manual may void the warranty.

IMPORTANT SAFEGUARDS

Please read all the instructions to familiarize yourself with all the parts and operations before use.



DO NOT touch hot surfaces.

- High temperature will cause scalding.
- Hot water and steam can severely burn skin.

DO NOT use machine with wet hands to avoid electric shock.

- This product is for **COMMERCIAL USE ONLY**.
- **DO NOT** use this unit for other than intended use.
- **DO NOT** operate unattended.
- Keep children and animals away from unit.
- **ALWAYS** use on a firm, dry and level surface, at least 12" from walls or any other obstruction.
- **DO NOT** immerse unit, cord or plug in liquid at any time.
- Keep cords, plugs, and other electrical components away from liquids to protect against electrical shock.
- **DO NOT** operate the unit outdoors.
- **DO NOT** operate the unit after it has malfunctioned or been damaged in any way.
- **DO NOT** plug into a socket where several other appliances are plugged in.
- **DO NOT** open the cooker to replace spare parts by yourself.
- **DO NOT** use the cooker close to flame or wet places.
- **DO NOT** place on unstable surfaces.
- **DO NOT** move the cooker together with a pot or while in use and hot.
- **DO NOT** heat a pot empty or overheat to avoid dry boiling.
- **DO NOT** place metallic objects such as knives, forks, spoons, lids, cans, and aluminum foils on the top plate.
- Use the unit with sufficient space around it. Keep the front side and either right or left side of the unit clear.
- **DO NOT** use the unit on carpet or tablecloth (vinyl) or any other low-heat-resistant article.
- **DO NOT** place a sheet of paper between the pot or the pan and the unit. The paper may get burnt.
- If the surface is cracked, switch off and take to the service center immediately.
- **DO NOT** block air intake or exhaust vent.
- **DO NOT** touch the top plate right after removing the pot or the pan, as the top plate will still be very hot.
- **DO NOT** place the cooker close to the objects which are affected by magnet, such as: radios, televisions, automatic-banking cards or cassette tapes.
- The base of the unit is liable to get hot during use.
- **DO NOT** use unit with a damaged cord or plug, in the event the appliance malfunctions, or has been damaged in any manner.
- **UNPLUG** the unit when not in use and before cleaning.
- **PROPER GROUNDING REQUIRED** Plug only into a 3-hole grounded electrical outlet.
- Check that your outlet and voltage are correct for the plug type before operating the unit.
- Any incorrect installation, alterations, adjustments and/or improper maintenance can lead to property loss and injury.



- The power cord must be replaced by qualified technicians.
- All repairs should be done by authorized professionals only.

General Safety

- **Read the Manual:** Thoroughly read and understand the manual before setting up, operating, or cleaning the unit.
- **Instruction and Training:** Ensure users are instructed and trained in the safe and correct operation of the unit to prevent accidents and ensure consistent results.
- **No Modifications:** Never modify the unit's settings, components, or features, or use such components or features in unintended ways outside of the manufacturer's specifications, as this may compromise safety and void warranties.
- **Wear Proper Apparel:** Always wear appropriate clothing. Avoid loose-fitting or hanging garments while operating the unit to prevent potential hazards.
- **Supervision Required:** This appliance is not intended for use by persons who lack experience and knowledge unless they are supervised or instructed in the safe use of the appliance by a person responsible for their safety.

Electrical Safety

Dedicated Circuit:

- For optimal performance and safety, the unit must be connected to a dedicated electrical circuit. Sharing a circuit with other appliances can lead to power fluctuations, potential tripping of the circuit breaker, and a reduced lifespan of the appliance.

GFCI Outlets:

- It is recommended to use the unit with a GFCI outlet. State and local regulations may require their use.

GFCI Troubleshooting:

- A GFCI receptacle protects against "ground faults" whenever an electrical product is plugged into the GFCI outlet by constantly monitoring the electricity for any loss of current. The heater element may absorb some moisture into its casing and insulation during shipment or during long periods of not being used. If the unit trips your GFCI upon first use, plug the unit into a non-GFCI outlet, set it to max temperature, and let it run for 30~60 minutes to dry out any moisture the element may have absorbed. After drying the element, plug the unit into the GFCI outlet; the unit should run without tripping the GFCI. If the unit still trips the GFCI, contact customer service.

Operational Safety

- **Overheat Control:**
 - Monitor the unit to prevent overheating, especially during extended use.
 - Ensure adequate ventilation to maintain safe operation.
- **No Flammable Materials:**
 - Avoid using the unit near flammable materials to prevent the risk of fire. Ensure no items are stored on top of the appliance during operation.

Installation

Inspect the Packaging:

- Examine the unit's packaging for any signs of damage that may have occurred during shipping. If damage has occurred, please reach out to the manufacturer immediately.

Unboxing:

- Open the packaging with care. Use scissors or a box cutter to cut open the box, ensuring you do not damage the unit or its components.
- Remove the machine from its packaging.
- Ensure that all foam and plastic have been removed from both the inside and outside of the machine before use.

Placement:

- Ensure a minimum clearance of 12" on all sides from flammable surfaces.
- Place the unit on a stable surface near an electrical outlet.
- It is required to place the unit in a climate-controlled room to enhance its durability.
- Level placement is crucial for the unit to work effectively.

Exhaust Canopy

- Compliance with Codes: Exhaust installation must comply with local codes.

To Use

- First prepare the ingredients you plan to cook in the pan (wash, marinate and season them) and if necessary, put a thin layer of oil or grease in the pan. Let moist foods dry.
 - Put the plug in a proper power point. The indicator light will go up (green).
 - Turn the switch to the right until you hear a click. The switch is now set to "POWER". The indicator light will turn red. The appliance is now set to keeping the pan warm.
 - Turn the switch towards "MAX" to increase power.
- The cooking process can be stopped by turning the thermostat switch to "On/Off" or by turning the knob removing the plug from the socket.
 - Always disconnect the plug from the socket when you have finished cooking.

Usable and Non-Usable Utensils

- Usable Pans: Steel or Cast Iron, Enameled Iron, Stainless steel, Flat-bottom Pans / Pots with diameter from 12 to 26cm.



- Non-usable Pans: Heat-resistant glass, ceramic container, copper, aluminum pans/pots. Rounded-bottom pans/pots with bottom measuring less than 12cm.





Maintenance

How to Clean

1. Unplug and wait until the cooker is cooled down completely. Clean the cooker after using each time.
2. If the pots/pans are used without being cleaned, discoloration or cooked on stains may be caused.
3. Do not use benzine, thinner, scrubbing brush or polishing powder to clean the induction cooker.
4. Wipe using dish washing agent and damp cloth.
5. Use vacuum cleaner to suck up dirt from the air intake and exhaust vent.
6. Never run water over the unit (Water gets inside may cause malfunction).

Specifications

Model	IND-C208V
Unit Dimensions (in. / mm)	13.31" x 15.55" x 4.61"
Product Weight (lbs.)	13.8
Electrical	208V ~ 60Hz – 3000W (14.42A)
Plug Type	NEMA 6-20P



1 YEAR LIMITED WARRANTY

ONE (1) YEAR LIMITED WARRANTY ON PARTS AND APPROVED STRAIGHT-TIME LABOR

(subject to limitations below)

The Legacy Companies (the "Company") warrants this product (the "Product") will be free from defects in material and workmanship under normal use and service as specified by the Company for duration of:

- One (1) Year Limited Warranty on Parts and Approved Straight-Time Labor

This Limited Warranty is non-transferable.

During the Warranty Period, your exclusive remedy is repair or replacement without charge of the Product or any component found to be defective at the Company's discretion. If the Product or any component is no longer available, the Company will replace it with a similar one of equal or greater value.

The Warranty Period begins on the earliest of: (a) documented installation date; (b) date of purchase; or (c) date of shipment from the Company. In all cases, the Warranty Period shall not begin later than six (6) months after shipment.

The obligation of the Company under this warranty is limited to the repair or replacement, at the Company's sole discretion, of defective parts or assemblies that are reported during the Warranty Period and determined by the Company to be defective but excluding all labor charges (except as provided in the next paragraph).

The Company will cover approved straight-time labor only, performed during normal business hours, for covered defects reported within the applicable labor warranty period. Labor coverage excludes overtime, premium rates, travel exceeding one hundred (100) miles round-trip, multiple service trips, and access delays.

Costs expressly excluded from this warranty include, but are not limited to:

- Adjustments
- Cleaning and/or sanitizing
- Consumable/wearable items, such as gaskets, filters, light bulbs, legs, casters, hinges, non-stick cooking surfaces, etc.
- Labor to remove and/or install replacement equipment
- Disposal of defective equipment
 - Improper or inadequate utility connections, including but not limited to: Voltage outside of data plate specifications
 - Improper gas pressure
 - Improper gas supply
 - Water pressure outside of specified range
 - Poor water quality
 - Non-use or incorrect use of water filtration system
- External drain malfunction.
- Adverse operating conditions as set forth in the owner/user manual for the product.
- Non-authorized modification of the product.
- Improper installation of the product, including installation in a hostile environment
- Improper maintenance, abuse or misuse of the product.
- Causes beyond the reasonable control of the Company, including without limitation fires, freezing, floods and other natural disasters.
- Damage during transit.

No warranty shall apply to any product on which the model or serial number has been altered or removed. Adjustments or modifications to any equipment manufactured by the Company are not covered by this warranty.

This Warranty only extends to the original owner/end user and is not transferable or applicable to products sold through unauthorized channels.

This Warranty covers installations for Commercial use only. Installation or use in any residential or non-commercial setting voids all warranty coverage.

This warranty applies to the original installation location only.

IMPORTANT INSTALLATION NOTICE: Equipment installed outdoors or in mobile or non-permanent environments (including food trucks, trailers, RVs, or boats) is limited to a thirty (30) day warranty unless expressly approved in writing by the Company.

All warranty requests are to be made through the Company's Warranty and Technical Service team. All warranty requests shall include the product model and serial number, original installation date and/or Proof of Purchase, photo of the equipment serial number data plate and complete customer identification and location.

Replacement parts may be new or rebuilt at the Company's discretion and are warranted for the longer of ninety (90) days or the remaining original Warranty Period. Company and its agents are expressly permitted to specify rebuilt parts as suitable replacement parts. All replacement parts must be approved Company parts obtained through the Company or a Company approved parts distributor.

THIS WARRANTY IS IN LIEU OF ALL IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, PERFORMANCE, OR OTHERWISE, WHICH ARE HEREBY EXCLUDED. IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY DAMAGES, WHETHER DIRECT, INDIRECT, INCIDENTAL, FORESEEABLE, CONSEQUENTIAL, OR SPECIAL ARISING OUT OF OR IN CONNECTION WITH THIS PRODUCT INCLUDING DAMAGES ARISING FOR LOSS OF PROFIT, FOOD OR BEVERAGE SPOILAGE CLAIMS, OR OTHER COMMERCIAL LOSS.

You may have other legal rights depending upon where you live. Some States or Provinces do not allow limitations on warranties so the foregoing may not apply to you.