



INSTRUCTION MANUAL

55in Modern Console Stand with Cabinet

Ver. 1 SKY6445

(!) NOTICE

Please retain these instructions for future reference.

- · Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not firmly tighten the screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- · Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

TOOLS REQUIRED





132 LBS

CAPACITY

PER SHELF



CAPACITY


TOTAL







UP TO 45 MIN. ASSEMBLY


HARDWARE



























PARTS






Both the part 2 & 3 have a top & bottom based on their corresponding hardware. Make sure their orientation is correct before securing.

PRODUCT ASSEMBLY



Attach the part 3 bottom shelf to the parts 8 & 9 frames with eight part A bolts.

Attach the part 2 shelf to the part 8 side frames with four part A bolts.






Both the part 4 & 5 have a front & back based on their corresponding hardware. Make sure their orientation is correct before securing.

PRODUCT ASSEMBLY



Insert the part 4 & 5 cabinet side panels into their respective part 9 central frames. Secure with four part D screws,


Secure the part 2 shelf to the part 9 central frames and cabinet side panels with four part C



PRODUCT ASSEMBLY


3

Connect the part 6 cabinet back panels with two part E dowels.



4

Connect the part 6 back panel to the part 2 middle shelf with two part E dowels.




PRODUCT ASSEMBLY



Insert two part E dowels into the top of the part 6 back panels, then place the part 1 top


Secure the part 1 top to the part 8 side frames with four part A bolts, then secure the part 9 frames with four part B bolts.



PRODUCT ASSEMBLY


6

Attach two part I hinges to one part 7 cabinet door with four part F screws, two screws per hinge. Attach one part H handle with two part G fastening screws.



Attach one part 7 door assembly to the part 5 cabinet side panel with eight part F screws.


Repeat to attach the remaining door assembly to the part 4 right cabinet side.



WALL MOUNTING




Select an appropriate location, then mark two spaces on the wall using the part L anchor straps. Use a drill on the marked spaces.



WALL MOUNTING

2

Insert two part K wall anchors into the inner holes. Replace the straps, overlap the bookshelf frame, then attach the part L anchor straps with four part J wall screws.



Earn points while you shop. Join today!

bestchoice products reward\$

Join | Earn | Redeem

Give your friends 15% off their first order! For each successful referral you'll receive 100 points.

bestchoiceproducts.com



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com











PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.