


## ASSEMBLY INSTRUCTION






This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage. Attach Legs (B) to Stretcher (C) by Bolt (D) and Allen Wrench (E) as shown.




Attach assembled metal base to Wood Top (A) by Bolt (D) and Allen Wrench (E) as shown.




## **Cleaning & Care**


Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

## ASSEMBLY INSTRUCTION






This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage. Attach Legs (B) to Stretcher (C) by Bolt (D) and Allen Wrench (E) as shown.



Attach assembled metal base to Wood Top (A) by Bolt (D) and Allen Wrench (E) as shown.



## **Cleaning & Care**

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.