

~~1-1-32-832~~ Rail Replacement



FIG. 1

1. Make sure the table is upright before replacing the rail.



FIG. 2

2. Remove four Wood Screws underneath the rail.

Note: Save the screws for re-assembly.



FIG. 3

3. Take off the top rails by gently hammering the rail from underneath.



FIG. 4

4. Removing the rail.



FIG. 5

5. Replace the new rail.

Note: Make sure the top rail groove sits on the apron.



FIG. 6

6. To prevent the top rail from damage, cover the top rail with cardboard when hammering the rail back into place.



FIG. 7

7. Press and screw the rail together.



FIG. 8

8. Tighten four screws.



FIG. 9

9. Finished

CAUTION: We recommend that two adults work together to assemble this table.

- To replace the Apron, the table will need to be upside down. This is a very heavy table and turning it over will require at least two strong adults.

Replace Apron



FIG. 1



FIG. 1A



FIG. 1B

1. Hammering the Apron softly and remove from the table. See Fig. 1A.

Note: Make sure to remove the glue, nail and dust before replacing with new Apron. See Fig. 1B.



FIG. 2

2. Take the new Apron out of the parts box, place the Apron into the groove on the top rail.



FIG. 3

3. Hammer the Apron softly to make sure the Apron is positioned in groove.



FIG. 4

4. Attached the Apron to the cross support and playfield with the four screws that came from the parts box.



FIG. 5

5. Finished