












ASSEMBLY INSTRUCTION

E423-15(3A) MIRROR DESK WITH DRAWER

| | | | |
|--|---|---|---|
| A Mirrored Top  1pc | B Metal Frame  1pc | C Front Right Leg  1pc | D Front Left Leg  1pc |
| E Back Leg  2pcs | F Short Stretcher  2pcs | G Long Stretcher  1pc | H Knob  1pc <p>** Pre-attached to the inside of drawer **</p> |
| I Bolt 1/4"x5/8"  22pcs | J End Cap  4pcs | K Allen Wrench  1pc | |




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

***** Do not tighten screws & bolts until the entire unit is completely assembled.**


1

Attach metal frame (B) to mirrored top (A) using bolt (I) and allen wrench (K) as shown.




2

Attach front right leg (C), front left leg (D) and back leg (E) to mirrored top (A) using bolt (I) and allen wrench (K) as shown.



3



Using bolt (I) and allen wrench (K) again, attach short stretcher (F) between front right leg (C)/back leg (E), and front left leg (D)/back leg (E). Then, attach long stretcher (G) to back leg (E) as shown. Attach end cap (J) to leg (C) (D) (E). Please tighten all bolts at this step.

**4**

Carefully turn the assembled unit upright.

Remove drawer knob w/ plastic washers (H) from inside of the drawer and reattach on drawer front as shown. The mirrored desk assembly is now complete.

* © - The two plastic washers are for the purpose of protecting mirror surface. Please place one of the washers inside of the drawer and place the other one between front of the drawer and drawer knob.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.