



BEST CHOICE  
PRODUCTS



# INSTRUCTION MANUAL

---

88 Key Digital Piano with Fully  
Weighted Keys and U Type Stand

# **WARNING:**

- Only use the provided power adapter. Do not use damaged adapters.
- Do not disassemble the instrument or modify internal parts. If it malfunctions, discontinue use until repairs have been made.
- Turn off power before connecting this instrument to other devices.
- Do not play the instrument at maximum volume or at an uncomfortable level for an extended period of time.
- Be aware that excessive sound pressure from headphones can cause hearing loss.
- Overheating the instrument may cause damage; keep all parts of the instrument off and away from heat sources.
- Prevent liquid, dust, particles, and other foreign matter from entering the instrument because it may cause corrosion or short-circuit the components.
- Unplug the instrument before cleaning it. Do not insert or pull the plug out with wet hands.
- Use dry, soft cloth to clean the instrument. Do not use alcohol or other chemical solvents to wipe the instrument. Using these substances may damage the instrument surface.
- Turn off the power supply and unplug the instrument when not in use or if instrument breaks.
- To reduce risk of fire or electric shock, do not expose instrument to rain or humidity.
- Do not expose instrument to dripping or splashing liquid. Do not place objects filled with liquid on the instrument.
- Do not install this instrument in a confined space such as a book case or similar unit. Keep instrument in a well-ventilated area.
- To prevent possible harm to the environment, recycle this responsibly to promote the sustainable reuse of material resources.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- Before connecting or cutting off the AC transformer, make sure the power is off.
- To Troubleshoot the keyboard functions, turn power off and on.
- This product is intended for residential use only.

## **FCC COMPLIANCE STATEMENT**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This product may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**WARNING:** Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

*Responsible party (contact for FCC matters only):*

Quality Control Dept.  
15101 Red Hill Ave.  
Tustin, CA 92780


## COMPONENTS




- 1. Keyboard
- 2. Power Adapter
- 3. Sheet Music Stand
- 4. U-Type Stand
- 5. Keyboard Cover
- 6. Triple Sustain Pedal
- 7. Bench

# MAIN DIAGRAM

## CONTROL FRONT PANEL



## EXTERNAL PORTS ON THE REAR PANEL



## FUNCTION INTRODUCTION

- 88 Key (A1-C9) strength standard piano
- 880 timbre (true 140 timbre), 600 rhythm (true 128 rhythm), 100 demonstration songs
- 128 Polyphony
- Digital tube display
- Accompaniment volume control key
- Speed control keys
- Shift control keys
- Mode selection key (timbre, rhythm)
- Recording and playback functions
- Synthetic chords
- Demonstrate the function of singing together
- Metronome function
- Double keyboard function, double timbre function
- Keyboard drum function
- Start/stop, sync function keys, insert
- Soft pedal, Delay pedal, Damper pedal

## USING POWER ADAPTOR



Do not use any other power supply adaptor other than the one supplied with this unit. Connect one side to the power supply socket on the back-panel and the other side to an outlet.

**NOTE:** The input voltage (DC 15V) should be compatible with the outlet power.

## THE CONNECTIONS



### AUDIO INPUT INTERFACE

Before the audio signal is connected to the product, be sure to turn down the volume of the audio source first. After the connection is completed, the volume can return to desired level.




### AUDIO OUTPUT TERMINAL


Before you connect the audio amplifier, be sure to turn down the volume on the digital piano. Once the connection is complete, the volume can be returned to desired level.



## THE PEDALS





- 1. SOFT PEDAL:** after pressing the soft pedal, the keys played will be lowered in volume until after the pedal is released.
- 2. DELAYED TONE:** press the delayed tone pedal, there will be a sustain to only the note being played by the effect
- 3. DAMPER PEDAL:** after pressing the damper pedal, pressing the keys produces a lengthening effect.



## USB INTERFACE

The USB port of this digital piano can be connected with a music device with a USB connection to a computer. By Pre-Installing music software on your computer, you can play, compose, edit and store music.



Use universal USB cables to connect the digital piano to the computer and power it on.



## HEADPHONE OUTPUT TERMINAL

This product has two headphone output ports.

Connecting the headphones will automatically disconnect the digital piano built-in speaker output so you can play without disturbing others.



## BASIC OPERATION

### HOW TO PLAY

1. Hold down the “power” button. The display screen will light up and go into normal playing mode.
2. Adjust the volume to desired level
3. Play music on the keyboard.

### HOW TO CHOOSE THE TONE/TIMBRE

This product has 800 built-in tones/timbres. Please follow the steps below to select desired tone.

1. Find the desired timbre in the timbre list.
2. Press the Tone to enter Tone mode.
3. Select your desired Tone by selecting “+” or “-” key.

**NOTE:** Tone numbers are (0-799)

### HOW TO CHOOSE A RHYTHM

There are 600 rhythms built into this product. Follow the steps below to select desired Rhythm.

1. Press the Rhythm key to enter the Rhythm mode.
2. Select the desired Rhythm by pressing the “+” or “-” key.
3. Press “start/stop” to play Rhythm.
4. To stop the Rhythm, press “Start/Stop” again.

**NOTE:** Rhythm numbers are (0-599)

### HOW TO ADJUST THE TEMPO

1. Press the Tempo key to enter the Tempo adjustment mode.
2. Select desired tempo by selecting “+” or “-”

## AUTOMATIC ACCOMPANIMENT

### COMPREHENSIVE CHORD ACCOMPANIMENT

1. Press the “start/stop” button to start playing
2. Press the “chord” button to enter the chord state
  - Use Single-Multifingered chord patterns
3. Play Chords
  - Press on the keyboard (1-22 keys from left)
4. Press the “chord” button again to end chord state



### START SIMULTANEOUSLY

This product can be configured to play a rhythm at the same time of accompaniment chords.

**NOTE:** Before you begin, first choose the rhythm, set the tempo value, and select chords for accompaniment.

1. In chord state, press the “sync” button to enter the synchronous startup standby state.
2. Play the chords and the accompaniment will start playing automatically.
3. To end “Sync” mode, press “start/stop” button

### HOW TO PLAY DEMO SONGS

This product contains 100 built-in demo songs (see list of demo songs).

1. Find desired song number from demo song list
2. Press the “demo” button to enter demo song type
3. Select the song by pressing the “+” or “-” keys
4. Press the “demo” key again or “start/stop” key to stop play and exit the mode

**NOTE:** Demo Songs are (0-99) and will continue to play in sequence until you exit the mode.

## ADDITIONAL FEATURES

### HOW TO USE TOUCH FEATURE

This keyboard is enabled with a Touch Sensitivity feature that will allow the note being played to correspond to the velocity of the key being pressed. Volume depends on how hard the key is pressed.

The Touch feature is on by default. To turn off touch feature, press “touch”

### HOW TO USE PERCUSSION FUNCTIONS

Press the “Drum” button to turn the digital piano into a drum keyboard. Press again to turn function off.

### HOW TO USE DUAL TONES

The Dual Tone feature allows you to play two tones simultaneously.

1. First enter the tone mode and choose a tone
2. Press the “dual” button to enter the second tone
3. Use the “+” or “-” keys to select a second tone

### HOW TO SPLIT THE KEYBOARD

Using this feature will split the keyboard into two different tones.

1. Enter the tone mode and choose a tone
2. Press the “Split” key to enter split mode
3. Use the “+” or “-” keys to select a second tone
4. Press “split” again to end mode

### METRONOME

Press the metronome button to turn on and select “+” or “-” to change the tempo.

### RECORDING

1. Press the “record” button to enter recording mode
2. The maximum number of recordings is 250 notes
3. Each time the record button is pressed, the previous recording overwritten by the new recording

### PLAY

Press the “play” button to playback recordings

### MP3 FUNCTION

1. Directly enter mp3 mode after connecting usb flash disk into drive on front panel
2. Press “start/stop” buttons to start and pause playback
3. Press “+” or “-” to select songs on drive

## TROUBLE SHOOTING

PROBLEM	SOLUTION
When the Power is turned on, there is noise	This is normal, and means the current is entering the machine
There is noise when using a mobile phone	Using a mobile phone in the vicinity of the keyboard produces radiation To avoid this, turn off mobile phone or stay away from instrument
When the keyboard is played, there is no sound	Verify that the headphone jack is not plugged in
The chosen Tone has low volume	Verify that master volume is at desired level and dual tone is not engaged
A sound anomaly in timbre or rhythm	AC voltage is low
Tone is distorted	Volume is too high; it should be less than $\frac{3}{4}$ position
The accompaniment is not pronounced properly	Make sure the accompaniment volume is set to the appropriate level

# U-STAND ASSEMBLY

## TOOLS



PH 1 PHILLIPS  
SCREWDRIVER  
(OPTIONAL)



1 PERSON  
ASSEMBLY



UP TO 45 MIN.  
ASSEMBLY

## U-STAND HARDWARE

1

SCREW



13 PCS

2

PLASTIC  
WASHER



4 PCS

3

MOUNTING  
KNOB



2 PCS

4

LARGE SLIDER  
STICKER



4 PCS

5

SMALL SLIDER  
STICKER



2 PCS

6

SQUARE  
SLIDER  
STICKER




2 PCS

## U-STAND PARTS

A

UPPER FRAME  
BAR



1 SET

B

LOWER FRAME  
BAR



1 SET

C

LOWER  
FRAME BAR  
CONNECTOR



1 PC

D

SUPPORT  
BRACE



2 PCS

E

LEG



2 PCS

F

MOUNTING  
STRAP



2 PCS

G

SEAT




1 PC

## U-STAND ASSEMBLY


1

Connect the two part A upper frame bars with one part 1 screw, then set aside.



2

Connect the two part B lower frame bars with by attaching them to the part C lower frame bar connector with two part 1 screw, then set aside.




## U-STAND ASSEMBLY

3

Attach two part E legs to the part B lower frame assembly with two part 2 plastic washers and two part 1 screws. Place the R on your right and the L on your left.


**NOTE:** When attaching the bars to the legs, make sure the notches in the mounting holes are pointing downward.

Attach two part A upper frame bars to the part E legs with two part 2 plastic washers and two part 1 screws.



4

Attach two part D support braces to the part B lower frame bars with two part 1 screws, then attach to the part A upper frame bars with two more part 1 screws.



## U-STAND ASSEMBLY


5

Attach one part 4 large slider sticker to each end of the part E legs, four stickers total.

Attach one part 5 small slider sticker to the round recesses on the part A upper frame bars, two stickers total.

Attach two part 6 square slider stickers to the square recesses on the bottom of the part B bottom frame bars.


**NOTE:** Peel the white covering off the stickers before attaching.



6

Insert two part 3 mounting knobs into the part F mounting straps, then attach the straps to each of the part A upper frame bars with one part 1 screw each.

**NOTE:** Insert the screw in the single round hole on one end of the strap, and the knob into the square holes.




## MOUNTING THE PIANO

Place the keyboard onto the assembled stand.

**NOTE:** We recommend two people lift the keyboard.

Insert the part 3 mounting knobs into the threaded openings on the bottom of the keyboard, then tighten to secure.




## PREPARING THE SEAT

Locate the part G seat and unfold the legs.

**NOTE:** One leg is already fixed to the bottom of the seat, and the other is not.

Take hold of the unattached leg, and insert the top into the two plastic hooks on the bottom of the seat. Press into the hooks until secure, indicated by an audible click.

Place the seat on a flat, level surface and push down to secure.



# TONES

## THE PIANO

0. Piano 1
1. Piano 2
2. Piano 3
3. Honky-Tonk Piano
4. Rhodes Piano
5. Chorused Piano
6. Harpsichord
7. Clavinet

## PERCUSSION INSTRUMENTS

8. Celesta
9. Glockenspiel
10. Music Box
11. Vibraphone
12. Marimba
13. Xylophone
14. Tubular Bells
15. Santur

## THE ORGAN

16. Hammond Organ
17. Percussive Organ
18. Rock Organ
19. Church Organ
20. Reed Organ
21. Accordion
22. Harmonica
23. Bandoneon

## THE GUITAR

24. Acoustic Guitar (Nylon)
25. Acoustic Guitar (Steel)
26. Electric Guitar (Jazz)
27. Electric Guitar (Clean)
28. Electric Guitar (Nylon)
29. Overdriven Guitar
30. Distortion Guitar
31. Guitar Harmonics

## BASS

32. Acoustic Bass
33. Electric Bass (Finger)
34. Electric Bass (Pick)
35. Fretless Bass
36. Slap Bass 1
37. Slap Bass 2
38. Synth Bass 1
39. Synth Bass 2

## STRING SOLO

40. Violin
41. Viola
42. Cello
43. Contrabass

44. Tremolo Strings
45. Pizzicato Strings
46. Orchestral Harp
47. Timpani

## CHORAL ENSEMBLES

48. String Ensemble 1
49. String Ensemble 2
50. Synth Strings 1
51. Synth Strings 2
52. Choir Aahs
53. Voice Oohs
54. Synth Voice
55. Orchestra Hit

## THE BRASS

56. Trumpet
57. Trombone
58. Tuba
59. Muted Trumpet
60. French Horn
61. Brass Section
62. Synth Brass 1
63. Synth Brass 2

## REED INSTRUMENTS

64. Soprano Sax
65. Alto Sax
66. Tenor Sax
67. Baritone Sax
68. Oboe
69. English Horn
70. Bassoon
71. Clarinet

## WIND INSTRUMENTS

72. Piccolo
73. Flute
74. Recorder
75. Pan Flute
76. Bottle Blow
77. Shakuhachi
78. Whistle
79. Ocarina

## SYNTHESIS OF TONIC

80. Lead 1 (Square)
81. Lead 2 (Sawtooth)
82. Lead 3 (Calliope Lead)
83. Lead 4 (Chiff Lead)
84. Lead 5 (Charang)
85. Lead 6 (Voice)
86. Lead 7 (Fifths)
87. Lead 8 (Bass+Lead)

## SYNTHETIC SOFT TONE

88. Pad 1 (New Age)
89. Pad 2 (Warm)
90. Pad 3 (Polysynth)
91. Pad 4 (Choir)
92. Pad 5 (Bowed)
93. Pad 6 (Metallic)
94. Pad 7 (Halo)
95. Pad 8 (Sweep)

## SYNTHESIS OF SPECIAL EFFECTS

96. FX 1 (Rain)
97. FX 2 (Soundtrack)
98. FX 3 (Crystal)
99. FX 4 (Atmosphere)
100. FX 5 (Brightness)
101. FX 6 (Goblins)
102. FX 7 (Echoes)
103. FX 8 (Sci-fi)

## SYNTHESIS OF SPECIAL EFFECTS

104. Sitar
105. Banjo
106. Shamisen
107. Koto
108. Alimba
109. Bagpipe
110. Fiddle
111. Shanai

## PERCUSSION

112. Tinkle Bell
113. Agogo
114. Steel Drums
115. Woodblock
116. Taiko Drum
117. Melodic Tom
118. Synth Drum
119. Reverse Cymbal

## SOUND EFFECTS

120. Guitar Fret Noise
121. Breath Noise
122. Seashore
123. Bird Tweet
124. Telephone Ring
125. Helicopter
126. Applause
127. Gun Shot
128. PIPA
129. PIPA TRIM
130. LUAN
131. GUZHEN
132. ERHUVB

# TONES

133. FLUTE

## THE PIANO-2

- 134. Piano 1-2
- 135. Piano 2-2
- 136. Piano 3-2
- 137. Honky-Tonk Piano-2
- 138. Rhodes Piano-2
- 139. Chorused Piano-2
- 140. Harpsichord-2
- 141. Clavinet-2

## PERCUSSION INSTRUMENT-2

- 142. Celesta-2
- 143. Glockenspiel-2
- 144. Music Box-2
- 145. Vibraphone-2
- 146. Marimba-2
- 147. Xylophone-2
- 148. Tubular Bells-2
- 149. Santur-2

## THE ORGAN

- 150. Hammond Organ-2
- 151. Percussive Organ-2
- 152. Rock Organ-2
- 153. Church Organ-2
- 154. Reed Organ-2
- 155. Accordion-2
- 156. Harmonica-2
- 157. Bandoneon-2

## THE GUITAR-2

- 158. Acoustic Guitar (Nylon)-2
- 159. Acoustic Guitar (Steel)-2
- 160. Electric Guitar (Jazz)-2
- 161. Electric Guitar (Clean)-2
- 162. Electric Guitar (Nylon)-2
- 163. Overdriven Guitar-2
- 164. Distortion Guitar-2
- 165. Guitar Harmonics-2

## BASS-2

- 166. Acoustic Bass-2
- 167. Electric Bass (Finger)-2
- 168. Electric Bass (Pick)-2
- 169. Fretless Bass-2
- 170. Slap Bass 1-2
- 171. Slap Bass 2-2
- 172. Synth Bass 1-2
- 173. Synth Bass 2-2

## STRING SOLO-2

- 174. Violin-2
- 175. Viola-2
- 176. Cello-2
- 177. Contrabass-2

- 178. Tremolo Strings-2
- 179. Pizzicato Strings-2
- 180. Orchestral Harp-2
- 181. Timpani-2

## CHORAL ENSEMBLES-2

- 182. String Ensemble 1-2
- 183. String Ensemble 2-2
- 184. Synth Strings 1-2
- 185. Synth Strings 2-2
- 186. Choir Aahs-2
- 187. Voice Oohs-2
- 188. Synth Voice-2
- 189. Orchestra Hit-2

## THE BRASS-2

- 190. Trumpet-2
- 191. Trombone-2
- 192. Tuba-2
- 193. Muted Trumpet-2
- 194. French Horn-2
- 195. Brass Section-2
- 196. Synth Brass 1-2
- 197. Synth Brass 2-2

## REED INSTRUMENTS-2

- 198. Soprano Sax-2
- 199. Alto Sax-2
- 200. Tenor Sax-2
- 201. Baritone Sax-2
- 202. Oboe-2
- 203. English Horn-2
- 204. Bassoon-2
- 205. Clarinet-2

## WIND INSTRUMENTS

- 206. Piccolo-2
- 207. Flute-2
- 208. Recorder-2
- 209. Pan Flute-2
- 210. Bottle Blow-2
- 211. Shakuhachi-2
- 212. Whistle-2
- 213. Ocarina-2

## SYNTHESIS OF TONIC-2

- 214. Lead 1 (Square)-2
- 215. Lead 2 (Sawtooth)-2
- 216. Lead 3 (Calliope Lead)-2
- 217. Lead 4 (Chiff Lead)-2
- 218. Lead 5 (Charang)-2
- 219. Lead 6 (Voice)-2
- 220. Lead 7 (Fifths)-2
- 221. Lead 8 (Bass+Lead)-2

## SYNTHETIC SOFT TONE

- 222. Pad 1 (New Age)-2

- 223. Pad 2 (Warm)-2
- 224. Pad 3 (Polysynth)-2
- 225. Pad 4 (Choir)-2
- 226. Pad 5 (Bowed)-2
- 227. Pad 6 (Metallic)-2
- 228. Pad 7 (Halo)-2
- 229. Pad 8 (Sweep)-2

## SYNTHESIS EFFECTS-2

- 230. FX 1 (Rain)-2
- 231. FX 2 (Soundtrack)-2
- 232. FX 3 (Crystal)-2
- 233. FX 4 (Atmosphere)-2
- 234. FX 5 (Brightness)-2
- 235. FX 6 (Goblins)-2
- 236. FX 7 (Echoes)-2
- 237. FX 8 (Sci-fi)-2

## NATIONAL MUSICAL INSTRUMENTS-2

- 238. Sitar-2
- 239. Banjo-2
- 240. Shamisen-2
- 241. Koto-2
- 242. Alimba-2
- 243. Bagpipe-2
- 244. Fiddle-2
- 245. Shanai-2

## PERCUSSION-2

- 246. Tinkle Bell-2
- 247. Agogo-2
- 248. Steel Drums-2
- 249. Woodblock-2
- 250. Taiko Drum-2
- 251. Melodic Tom-2
- 252. Synth Drum-2
- 253. Reverse Cymbal-2

## SOUND EFFECTS-2

- 254. Guitar Fret Noise-2
- 255. Breath Noise-2
- 256. Seashore-2
- 257. Bird Tweet-2
- 258. Telephone Ring-2
- 259. Helicopter-2
- 260. Applause-2
- 261. Gun Shot-2
- 262. PIPA-2
- 263. PIPA TRIM-2
- 264. LUAN-2
- 265. GUZHEN-2
- 266. ERHUVB-2
- 267. FLUTE-2

## THE PIANO-3

## TONES

- 268. Piano 1-3
- 269. Piano 2-3
- 270. Piano 3-3
- 271. Honky-Tonk Piano-3
- 272. Rhodes Piano-3
- 273. Chorused Piano-3
- 274. Harpsichord-3
- 275. Clavinet-3

### PERCUSSION INSTRUMENT-3

- 276. Celesta-3
- 277. Glockenspiel-3
- 278. Music Box-3
- 279. Vibraphone-3
- 280. Marimba-3
- 281. Xylophone-3
- 282. Tubular Bells-3
- 283. Santur-3

### THE ORGAN-3

- 284. Hammond Organ-3
- 285. Percussive Organ-3
- 286. Rock Organ-3
- 287. Church Organ-3
- 288. Reed Organ-3
- 289. Accordion-3
- 290. Harmonica-3
- 291. Bandoneon-3

### THE GUITAR-3

- 292. Acoustic Guitar (Nylon)-3
- 293. Acoustic Guitar (Steel) -3
- 294. Electric Guitar (Jazz) -3
- 295. Electric Guitar (Clean) -3
- 296. Electric Guitar (Nylon) -3
- 297. Overdriven Guitar-3
- 298. Distortion Guitar-3
- 299. Guitar Harmonics-3

### BASS-3

- 300. Acoustic Bass-3
- 301. Electric Bass (Finger) -3
- 302. Electric Bass (Pick) -3
- 303. Fretless Bass-3
- 304. Slap Bass 1-3
- 305. Slap Bass 2-3
- 306. Synth Bass 1-3
- 307. Synth Bass 2-3

### STRING SOLO-3

- 308. Violin-3
- 309. Viola-3
- 310. Cello-3
- 311. Contrabass-3
- 312. Tremolo Strings-3
- 313. Pizzicato Strings-3

- 314. Orchestral Harp-3
- 315. Timpani-3

### CHORAL ENSEMBLES-3

- 316. String Ensemble 1-3
- 317. String Ensemble 2-3
- 318. Synth Strings 1-3
- 319. Synth Strings 2-3
- 320. Choir Aahs-3
- 321. Voice Oohs-3
- 322. Synth Voice-3
- 323. Orchestra Hit-3

### THE BRASS-3

- 324. Trumpet-3
- 325. Trombone-3
- 326. Tuba-3
- 327. Muted Trumpet-3
- 328. French Horn-3
- 329. Brass Section-3
- 330. Synth Brass 1-3
- 331. Synth Brass 2-3

### REED INSTRUMENTS-3

- 332. Soprano Sax-3
- 333. Alto Sax-3
- 334. Tenor Sax-3
- 335. Baritone Sax-3
- 336. Oboe-3
- 337. English Horn-3
- 338. Bassoon-3
- 339. Clarinet-3

### WIND INSTRUMENTS

- 340. Piccolo-3
- 341. Flute-3
- 342. Recorder-3
- 343. Pan Flute-3
- 344. Bottle Blow-3
- 345. Shakuhachi-3
- 346. Whistle-3
- 347. Ocarina-3

### SYNTHESIS OF TONIC-3

- 348. Lead 1 (Square)-3
- 349. Lead 2 (Sawtooth)-3
- 350. Lead 3 (Calliope Lead)-3
- 351. Lead 4 (Chiff Lead)-3
- 352. Lead 5 (Charang)-3
- 353. Lead 6 (Voice)-3
- 354. Lead 7 (Fifths)-3
- 355. Lead 8 (Bass+Lead)-3

### SYNTHETIC SOFT TONE-3

- 356. Pad 1 (New Age)-3
- 357. Pad 2 (Warm)-3
- 358. Pad 3 (Polysynth)-3

- 359. Pad 4 (Choir)-3
- 360. Pad 5 (Bowed)-3
- 361. Pad 6 (Metallic)-3
- 362. Pad 7 (Halo)-3
- 363. Pad 8 (Sweep)-3

### SYNTHESIS EFFECT-3

- 364. FX 1 (Rain)-3
- 365. FX 2 (Soundtrack)-3
- 366. FX 3 (Crystal)-3
- 367. FX 4 (Atmosphere)-3
- 368. FX 5 (Brightness)-3
- 369. FX 6 (Goblins)-3
- 370. FX 7 (Echoes)-3
- 371. FX 8 (Sci-fi)-3

### NATIONAL MUSICAL INSTRUMENTS-3

- 372. Sitar-3
- 373. Banjo-3
- 374. Shamisen-3
- 375. Koto-3
- 376. Alimba-3
- 377. Bagpipe-3
- 378. Fiddle-3
- 379. Shanai-3

### PERCUSSION-3

- 380. Tinkle Bell-3
- 381. Agogo-3
- 382. Steel Drums-3
- 383. Woodblock-3
- 384. Taiko Drum-3
- 385. Melodic Tom-3
- 386. Synth Drum-3
- 387. Reverse Cymbal-3

### SOUND EFFECTS-3

- 388. Guitar Fret Noise-3
- 389. Breath Noise-3
- 390. Seashore-3
- 391. Bird Tweet-3
- 392. Telephone Ring-3
- 393. Helicopter-3
- 394. Applause-3
- 395. Gun Shot-3
- 396. PIPA-3
- 397. PIPA TRIM-3
- 398. LUAN-3
- 399. GUZHEN-3
- 400. ERHUVB-3
- 401. FLUTE-3

### THE PIANO-4

- 402. Piano 1-4
- 403. Piano 2-4

## TONES

- 404. Piano 3-4
- 405. Honky-Tonk Piano-4
- 406. Rhodes Piano-4
- 407. Chorused Piano-4
- 408. Harpsichord-4
- 409. Clavinet-4

### PERCUSSION INSTRUMENT-3

- 410. Celesta-4
- 411. Glockenspiel-4
- 412. Music Box-4
- 413. Vibraphone-4
- 414. Marimba-4
- 415. Xylophone-4
- 416. Tubular Bells-4
- 417. Santur-4

### THE ORGAN-4

- 418. Hammond Organ-4
- 419. Percussive Organ-4
- 420. Rock Organ-4
- 421. Church Organ-4
- 422. Reed Organ-4
- 423. Accordion-4
- 424. Harmonica-4
- 425. Bandoneon-4

### THE GUITAR-4

- 426. Acoustic Guitar (Nylon)-4
- 427. Acoustic Guitar (Steel) -4
- 428. Electric Guitar (Jazz) -4
- 429. Electric Guitar (Clean) -4
- 430. Electric Guitar (Nylon) -4
- 431. Overdriven Guitar-4
- 432. Distortion Guitar-4
- 433. Guitar Harmonics-4

### BASS-4

- 434. Acoustic Bass-4
- 435. Electric Bass (Finger) -4
- 436. Electric Bass (Pick) -4
- 437. Fretless Bass-4
- 438. Slap Bass 1-4
- 439. Slap Bass 2-4
- 440. Synth Bass 1-4
- 441. Synth Bass 2-4

### STRING SOLO-4

- 442. Violin-4
- 443. Viola-4
- 444. Cello-4
- 445. Contrabass-4
- 446. Tremolo Strings-4
- 447. Pizzicato Strings-4
- 448. Orchestral Harp-4
- 449. Timpani-4

### CHORAL ENSEMBLES-4

- 450. String Ensemble 1-4
- 451. String Ensemble 2-4
- 452. Synth Strings 1-3
- 453. Synth Strings 2-4
- 454. Choir Aahs-4
- 455. Voice Oohs-4
- 456. Synth Voice-4
- 457. Orchestra Hit-4

### THE BRASS-4

- 458. Trumpet-4
- 459. Trombone-4
- 460. Tuba-4
- 461. Muted Trumpet-4
- 462. French Horn-4
- 463. Brass Section-4
- 464. Synth Brass 1-4
- 465. Synth Brass 2-4

### REED INSTRUMENTS-4

- 466. Soprano Sax-4
- 467. Alto Sax-4
- 468. Tenor Sax-4
- 469. Baritone Sax-4
- 470. Oboe-4
- 471. English Horn-4
- 472. Bassoon-4
- 473. Clarinet-4

### WIND INSTRUMENTS

- 474. Piccolo-4
- 475. Flute-4
- 476. Recorder-4
- 477. Pan Flute-4
- 478. Bottle Blow-4
- 479. Shakuhachi-4
- 480. Whistle-4
- 481. Ocarina-4

### SYNTHESIS OF TONIC-4

- 482. Lead 1 (Square)-4
- 483. Lead 2 (Sawtooth)-4
- 484. Lead 3 (Calliope Lead)-4
- 485. Lead 4 (Chiff Lead)-4
- 486. Lead 5 (Charang)-4
- 487. Lead 6 (Voice)-4
- 488. Lead 7 (Fifths)-4
- 489. Lead 8 (Bass+Lead)-4

### SYNTHETIC SOFT TONE-4

- 490. Pad 1 (New Age)-4
- 491. Pad 2 (Warm)-4
- 492. Pad 3 (Polysynth)-4
- 493. Pad 4 (Choir)-4
- 494. Pad 5 (Bowed)-4

- 495. Pad 6 (Metallic)-4
- 496. Pad 7 (Halo)-4
- 497. Pad 8 (Sweep)-4

### SYNTHESIS EFFECT-4

- 498. FX 1 (Rain)-4
- 499. FX 2 (Soundtrack)-4
- 500. FX 3 (Crystal)-4
- 501. FX 4 (Atmosphere)-4
- 502. FX 5 (Brightness)-4
- 503. FX 6 (Goblins)-4
- 504. FX 7 (Echoes)-4
- 505. FX 8 (Sci-fi)-4

### NATIONAL MUSICAL INSTRUMENTS-4

- 506. Sitar-4
- 507. Banjo-4
- 508. Shamisen-4
- 509. Koto-4
- 510. Alimba-4
- 511. Bagpipe-4
- 512. Fiddle-4
- 513. Shanai-4

### PERCUSSION-4

- 514. Tinkle Bell-4
- 515. Agogo-4
- 516. Steel Drums-4
- 517. Woodblock-4
- 518. Taiko Drum-4
- 519. Melodic Tom-4
- 520. Synth Drum-4
- 521. Reverse Cymbal-4

### SOUND EFFECTS-4

- 522. Guitar Fret Noise-4
- 523. Breath Noise-4
- 524. Seashore-4
- 525. Bird Tweet-4
- 526. Telephone Ring-4
- 527. Helicopter-4
- 528. Applause-4
- 529. Gun Shot-4
- 530. PIPA-4
- 531. PIPA TRIM-4
- 532. LUAN-4
- 533. GUZHEN-4
- 534. ERHUVB-4
- 535. FLUTE-4

### THE PIANO-5

- 536. Piano 1-5
- 537. Piano 2-5
- 538. Piano 3-5
- 539. Honky-Tonk Piano-5

## TONES

- 540. Rhodes Piano-5
- 541. Chorused Piano-5
- 542. Harpsichord-5
- 543. Clavinet-5

### PERCUSSION INSTRUMENT-5

- 544. Celesta-5
- 545. Glockenspiel-5
- 546. Music Box-5
- 547. Vibraphone-5
- 548. Marimba-5
- 549. Xylophone-5
- 550. Tubular Bells-5
- 551. Santur-5

### THE ORGAN-5

- 552. Hammond Organ-5
- 553. Percussive Organ-5
- 554. Rock Organ-5
- 555. Church Organ-5
- 556. Reed Organ-5
- 557. Accordion-5
- 558. Harmonica-5
- 559. Bandoneon-5

### THE GUITAR-5

- 560. Acoustic Guitar (Nylon)-5
- 561. Acoustic Guitar (Steel) -5
- 562. Electric Guitar (Jazz) -5
- 563. Electric Guitar (Clean) -5
- 564. Electric Guitar (Nylon) -5
- 565. Overdriven Guitar-5
- 566. Distortion Guitar-5
- 567. Guitar Harmonics-5

### BASS-5

- 568. Acoustic Bass-5
- 569. Electric Bass (Finger) -5
- 570. Electric Bass (Pick) -5
- 571. Fretless Bass-5
- 572. Slap Bass 1-5
- 573. Slap Bass 2-5
- 574. Synth Bass 1-5
- 575. Synth Bass 2-5

### STRING SOLO-5

- 576. Violin-5
- 577. Viola-5
- 578. Cello-5
- 579. Contrabass-5
- 580. Tremolo Strings-5
- 581. Pizzicato Strings-5
- 582. Orchestral Harp-5
- 583. Timpani-5

### CHORAL ENSEMBLES-5

- 584. String Ensemble 1-5

- 585. String Ensemble 2-5
- 586. Synth Strings 1-5
- 587. Synth Strings 2-5
- 588. Choir Aahs-5
- 589. Voice Oohs-5
- 590. Synth Voice-5
- 591. Orchestra Hit-5

### THE BRASS-5

- 592. Trumpet-5
- 593. Trombone-5
- 594. Tuba-5
- 595. Muted Trumpet-5
- 596. French Horn-5
- 597. Brass Section-5
- 598. Synth Brass 1-5
- 599. Synth Brass 2-5

### REED INSTRUMENTS-5

- 600. Soprano Sax-5
- 601. Alto Sax-5
- 602. Tenor Sax-5
- 603. Baritone Sax-5
- 604. Oboe-5
- 605. English Horn-5
- 606. Bassoon-5
- 607. Clarinet-5

### WIND INSTRUMENTS

- 608. Piccolo-5
- 609. Flute-5
- 610. Recorder-5
- 611. Pan Flute-5
- 612. Bottle Blow-5
- 613. Shakuhachi-5
- 614. Whistle-5
- 615. Ocarina-5

### SYNTHESIS OF TONIC-5

- 616. Lead 1 (Square)-5
- 617. Lead 2 (Sawtooth)-5
- 618. Lead 3 (Calliope Lead)-5
- 619. Lead 4 (Chiff Lead)-5
- 620. Lead 5 (Charang)-5
- 621. Lead 6 (Voice)-5
- 622. Lead 7 (Fifths)-5
- 623. Lead 8 (Bass+Lead)-5

### SYNTHETIC SOFT TONE-5

- 624. Pad 1 (New Age)-5
- 625. Pad 2 (Warm)-5
- 626. Pad 3 (Polysynth)-5
- 627. Pad 4 (Choir)-5
- 628. Pad 5 (Bowed)-5
- 629. Pad 6 (Metallic)-5
- 630. Pad 7 (Halo)-5

- 631. Pad 8 (Sweep)-5

### SYNTHESIS EFFECT-5

- 632. FX 1 (Rain)-5
- 633. FX 2 (Soundtrack)-5
- 634. FX 3 (Crystal)-5
- 635. FX 4 (Atmosphere)-5
- 636. FX 5 (Brightness)-5
- 637. FX 6 (Goblins)-5
- 638. FX 7 (Echoes)-5
- 639. FX 8 (Sci-fi)-5

### NATIONAL MUSICAL INSTRUMENTS-5

- 640. Sitar-5
- 641. Banjo-5
- 642. Shamisen-5
- 643. Koto-5
- 644. Alimba-5
- 645. Bagpipe-5
- 646. Fiddle-5
- 647. Shanai-5

### PERCUSSION-5

- 648. Tinkle Bell-5
- 649. Agogo-5
- 650. Steel Drums-5
- 651. Woodblock-5
- 652. Taiko Drum-5
- 653. Melodic Tom-5
- 654. Synth Drum-5
- 655. Reverse Cymbal-5

### SOUND EFFECTS-5

- 656. Guitar Fret Noise-5
- 657. Breath Noise-5
- 658. Seashore-5
- 659. Bird Tweet-5
- 660. Telephone Ring-5
- 661. Helicopter-5
- 662. Applause-5
- 663. Gun Shot-5
- 664. PIPA-5
- 665. PIPA TRIM-5
- 666. LUAN-5
- 667. GUZHEN-5
- 668. ERHUVB-5
- 669. FLUTE-5

### THE PIANO-6

- 670. Piano 1-6
- 671. Piano 2-6
- 672. Piano 3-6
- 673. Honky-Tonk Piano-6
- 674. Rhodes Piano-6
- 675. Chorused Piano-6

## TONES

- 676. Harpsichord-6
- 677. Clavinet-6

### PERCUSSION INSTRUMENT-6

- 678. Celesta-6
- 679. Glockenspiel-6
- 680. Music Box-6
- 681. Vibraphone-6
- 682. Marimba-6
- 683. Xylophone-6
- 684. Tubular Bells-6
- 685. Santur-6

### THE ORGAN-6

- 686. Hammond Organ-6
- 687. Percussive Organ-6
- 688. Rock Organ-6
- 689. Church Organ-6
- 690. Reed Organ-6
- 691. Accordion-6
- 692. Harmonica-6
- 693. Bandoneon-6

### THE GUITAR-6

- 694. Acoustic Guitar (Nylon)-6
- 695. Acoustic Guitar (Steel) -6
- 696. Electric Guitar (Jazz) -6
- 697. Electric Guitar (Clean) -6
- 698. Electric Guitar (Nylon) -6
- 699. Overdriven Guitar-6
- 700. Distortion Guitar-6
- 701. Guitar Harmonics-6

### BASS-6

- 702. Acoustic Bass-6
- 703. Electric Bass (Finger) -6
- 704. Electric Bass (Pick) -6
- 705. Fretless Bass-6
- 706. Slap Bass 1-6
- 707. Slap Bass 2-6
- 708. Synth Bass 1-6
- 709. Synth Bass 2-6

### STRING SOLO-6

- 710. Violin-6
- 711. Viola-6
- 712. Cello-6
- 713. Contrabass-6
- 714. Tremolo Strings-6
- 715. Pizzicato Strings-6
- 716. Orchestral Harp-6
- 717. Timpani-6

### CHORAL ENSEMBLES-6

- 718. String Ensemble 1-6
- 719. String Ensemble 2-6
- 720. Synth Strings 1-6

- 721. Synth Strings 2-6
- 722. Choir Aahs-6
- 723. Voice Oohs-6
- 724. Synth Voice-6
- 725. Orchestra Hit-6

### THE BRASS-6

- 726. Trumpet-6
- 727. Trombone-6
- 728. Tuba-6
- 729. Muted Trumpet-6
- 730. French Horn-6
- 731. Brass Section-6
- 732. Synth Brass 1-6
- 733. Synth Brass 2-6

### REED INSTRUMENTS-6

- 734. Soprano Sax-6
- 735. Alto Sax-6
- 736. Tenor Sax-6
- 737. Baritone Sax-6
- 738. Oboe-6
- 739. English Horn-6
- 740. Bassoon-6
- 741. Clarinet-6

### WIND INSTRUMENTS

- 742. Piccolo-6
- 743. Flute-6
- 744. Recorder-6
- 745. Pan Flute-6
- 746. Bottle Blow-6
- 747. Shakuhachi-6
- 748. Whistle-6
- 749. Ocarina-6

### SYNTHESIS OF TONIC-6

- 750. Lead 1 (Square)-6
- 751. Lead 2 (Sawtooth)-6
- 752. Lead 3 (Calliope Lead)-6
- 753. Lead 4 (Chiff Lead)-6
- 754. Lead 5 (Charang)-6
- 755. Lead 6 (Voice)-6
- 756. Lead 7 (Fifths)-6
- 757. Lead 8 (Bass+Lead)-6

### SYNTHETIC SOFT TONE-6

- 758. Pad 1 (New Age)-6
- 759. Pad 2 (Warm)-6
- 760. Pad 3 (Polysynth)-6
- 761. Pad 4 (Choir)-6
- 762. Pad 5 (Bowed)-6
- 763. Pad 6 (Metallic)-6
- 764. Pad 7 (Halo)-6
- 765. Pad 8 (Sweep)-6

### SYNTHESIS EFFECT-6

- 766. FX 1 (Rain)-6
- 767. FX 2 (Soundtrack)-6
- 768. FX 3 (Crystal)-6
- 769. FX 4 (Atmosphere)-6
- 770. FX 5 (Brightness)-6
- 771. FX 6 (Goblins)-6
- 772. FX 7 (Echoes)-6
- 773. FX 8 (Sci-fi)-6

### NATIONAL MUSICAL INSTRUMENTS-6

- 774. Sitar-6
- 775. Banjo-6
- 776. Shamisen-6
- 777. Koto-6
- 778. Alimba-6
- 779. Bagpipe-6
- 780. Fiddle-6
- 781. Shanai-6

### PERCUSSION-6

- 782. Tinkle Bell-6
- 783. Agogo-6
- 784. Steel Drums-6
- 785. Woodblock-6
- 786. Taiko Drum-6
- 787. Melodic Tom-6
- 788. Synth Drum-6
- 789. Reverse Cymbal-6

### SOUND EFFECTS-6

- 790. Guitar Fret Noise-6
- 791. Breath Noise-6
- 792. Seashore-6
- 793. Bird Tweet-6
- 794. Telephone Ring-6
- 795. Helicopter-6
- 796. Applause-6
- 797. Gun Shot-6
- 798. PIPA-6
- 799. PIPA TRIM-6

## RHYTHMS

0. Beguine Swing
1. Beguine 1
2. Beguine 2
3. Pophit
4. Pop
5. Popmalay
6. Bossanova
7. Disco 1
8. Disco 2
9. Bluegrass Disco
10. Waltz 1
11. Waltz 2
12. True Ballad Waltz
13. Bossa Waltz
14. Easy Waltz
15. Shuffle Waltz
16. Reggae Waltz
17. Rhumba Waltz
18. March 1
19. March 2
20. Rhumba 1
21. Rhumba 2
22. Slow 1
23. Slow 2
24. Discocha
25. Guaracha
26. Charl
27. Samba 1
28. Samba 2
29. Ubminimal
30. 18 Bit
31. 28 Bit
32. 16 Bit 1
33. 16 Bit 2
34. Ballad 16T
35. Country 16T
36. Tango 1
37. Tango 2
38. Polka 1
39. Polka 2
40. Pop Swing
41. Easy Swing
42. Soft Swing
43. Rock 1
44. Rock 2
45. Rock 3
46. Airy Rock
47. Heat Rock
48. Rock & Roll
49. Urban
50. Ballad
51. Jazz Ballad
52. C. Ballad
53. J. Ballad
54. 60 Slow Ballad
55. Piano Ballad
56. 50 Slow Ballad
57. Snakebase
58. Happy Blues
59. Old Blues
60. Bluegrass
61. Boodie 1
62. Boodie 2
63. Boodie 3
64. Shuffle 1
65. Shuffle 2
66. Dream Shuffle
67. Country Shuffle
68. Quick Shuffle
69. Reggae Shuffle
70. R&B
71. Reggae 1
72. Reggae 2
73. Reggae 3
74. Salsa 1
75. Salsa 2
76. Salsa 3
77. Techno 1
78. Techno 2
79. Funky 1
80. Funky 2
81. Dixie 1
82. Dixie 2
83. Foxtrot 1
84. Foxtrot 2
85. R. Roll 1
86. R. Roll 2
87. Fastbeat
88. Quickbeat
89. Smooth Beat
90. Square Beat
91. Euro Beat
92. Alphadance
93. Betadance
94. Dreamdance
95. Dance 1
96. Dance 2
97. Dance 3
98. Rap
99. The Village
100. Country Shuffle
101. Electric Keys
102. Dark Keys
103. Easy Walk
104. Destiny
105. Comedy
106. Drive
107. Liquid Nova
108. Industrial Folk
109. Slow Pure
110. Simple Jam
111. Synthethix
112. Feel
113. Accelerate
114. Beach Night
115. Irish
116. Tarantella
117. Bigband
118. Dandut
119. Fusion
120. Horse
121. Keron
122. Latin
123. Mambo
124. New Age
125. Slow RC
126. Soul
127. Twist
128. Beguine Swing-2
129. Beguine 1-2
130. Beguine 2-2
131. Pophit-2
132. Pop-2
133. Popmalay-2
134. Bossanova-2
135. Disco 1-2
136. Disco 2-2
137. Bluegrass Disco-2
138. Waltz 1-2
139. Waltz 2
140. True Ballad Waltz-2
141. Bossa Waltz-2
142. Easy Waltz-2
143. Shuffle Waltz-2
144. Reggae Waltz-2
145. Rhumba Waltz-2
146. March 1-2
147. March 2-2
148. Rhumba 1-2
149. Rhumba 2-2
150. Slow 1-2
151. Slow 2-2
152. Discocha-2
153. Guaracha-2
154. Charl-2
155. Samba 1-2

## RHYTHMS

156. Samba 2-2
157. Ubminimal-2
158. 18 Bit-2
159. 28 Bit-2
160. 16 Bit 1-2
161. 16 Bit 2-2
162. Ballad 16T-2
163. Country 16T-2
164. Tango 1-2
165. Tango 2-2
166. Polka 1-2
167. Polka 2-2
168. Pop Swing-2
169. Easy Swing-2
170. Soft Swing-2
171. Rock 1-2
172. Rock 2-2
173. Rock 3-2
174. Airy Rock-2
175. Heat Rock-2
176. Rock & Roll-2
177. Urban-2
178. Ballad-2
179. Jazz Ballad-2
180. C. Ballad-2
181. J. Ballad-2
182. 60 Slow Ballad-2
183. Piano Ballad-2
184. 50 Slow Ballad-2
185. Snakebase-2
186. Happy Blues-2
187. Old Blues-2
188. Bluegrass-2
189. Boogie 1-2
190. Boogie 2-2
191. Boogie 3-2
192. Shuffle 1-2
193. Shuffle 2-2
194. Dream Shuffle-2
195. Country Shuffle-2
196. Quick Shuffle-2
197. Reggae Shuffle-2
198. R&B-2
199. Reggae 1-2
200. Reggae 2-2
201. Reggae 3-2
202. Salsa 1-2
203. Salsa 2-2
204. Salsa 3-2
205. Techno 1-2
206. Techno 2-2
207. Funky 1-2
208. Funky 2-2
209. Dixie 1-2
210. Dixie 2-2
211. Foxtrot 1-2
212. Foxtrot 2-2
213. R. Roll 1-2
214. R. Roll 2-2
215. Fastbeat-2
216. Quickbeat-2
217. Smooth Beat-2
218. Square Beat-2
219. Euro Beat-2
220. Alphadance-2
221. Betadance-2
222. Dreamdance-2
223. Dance 1-2
224. Dance 2-2
225. Dance 3-2
226. Rap-2
227. The Village-2
228. Country Shuffle-2
229. Electric Keys-2
230. Dark Keys-2
231. Easy Walk-2
232. Destiny-2
233. Comedy-2
234. Drive-2
235. Liquid Nova-2
236. Industrial Folk-2
237. Slow Pure-2
238. Simple Jam-2
239. Synthethix-2
240. Feel-2
241. Accelerate-2
242. Beach Night-2
243. Irish-2
244. Tarantella-2
245. Bigband-2
246. Dandut-2
247. Fusion-2
248. Horse-2
249. Keron-2
250. Latin-2
251. Mambo-2
252. New Age-2
253. Slow RC-2
254. Soul-2
255. Twist-2
256. Beguine Swing-3
257. Beguine 1-3
258. Beguine 2-3
259. Pophit-3
260. Pop-3
261. Popmalay-3
262. Bossanova-3
263. Disco 1-3
264. Disco 2-3
265. Bluegrass Disco-3
266. Waltz 1-3
267. Waltz 2
268. True Ballad Waltz-3
269. Bossa Waltz-3
270. Easy Waltz-3
271. Shuffle Waltz-3
272. Reggae Waltz-3
273. Rhumba Waltz-3
274. March 1-3
275. March 2-3
276. Rhumba 1-3
277. Rhumba 2-3
278. Slow 1-3
279. Slow 2-3
280. Discocha-3
281. Guaracha-3
282. Charl-3
283. Samba 1-3
284. Samba 2-3
285. Ubminimal-3
286. 18 Bit-3
287. 28 Bit-3
288. 16 Bit 1-3
289. 16 Bit 2-3
290. Ballad 16T-3
291. Country 16T-3
292. Tango 1-3
293. Tango 2-3
294. Polka 1-3
295. Polka 2-3
296. Pop Swing-3
297. Easy Swing-3
298. Soft Swing-3
299. Rock 1-3
300. Rock 2-3
301. Rock 3-3
302. Airy Rock-3
303. Heat Rock-3
304. Rock & Roll-3
305. Urban-3
306. Ballad-3
307. Jazz Ballad-3
308. C. Ballad-3
309. J. Ballad-3
310. 60 Slow Ballad-3
311. Piano Ballad-3

## RHYTHMS

- 312. 50 Slow Ballad-3
- 313. Snakebase-3
- 314. Happy Blues-3
- 315. Old Blues-3
- 316. Bluegrass-3
- 317. Boogie 1-3
- 318. Boogie 2-3
- 319. Boogie 3-3
- 320. Shuffle 1-3
- 321. Shuffle 2-3
- 322. Dream Shuffle-3
- 323. Country Shuffle-3
- 324. Quick Shuffle-3
- 325. Reggae Shuffle-3
- 326. R&B-3
- 327. Reggae 1-3
- 328. Reggae 2-3
- 329. Reggae 3-3
- 330. Salsa 1-3
- 331. Salsa 2-3
- 332. Salsa 3-3
- 333. Techno 1-3
- 334. Techno 2-3
- 335. Funky 1-3
- 336. Funky 2-3
- 337. Dixie 1-3
- 338. Dixie 2-3
- 339. Foxtrot 1-3
- 340. Foxtrot 2-3
- 341. R. Roll 1-3
- 342. R. Roll 2-3
- 343. Fastbeat-3
- 344. Quickbeat-3
- 345. Smooth Beat-3
- 346. Square Beat-3
- 347. Euro Beat-3
- 348. Alphadance-3
- 349. Betadance-3
- 350. Dreamdance-3
- 351. Dance 1-3
- 352. Dance 2-3
- 353. Dance 3-3
- 354. Rap-3
- 355. The Village-3
- 356. Country Shuffle-3
- 357. Electric Keys-3
- 358. Dark Keys-3
- 359. Easy Walk-3
- 360. Destiny-3
- 361. Comedy-3
- 362. Drive-3
- 363. Liquid Nova-3
- 364. Industrial Folk-3
- 365. Slow Pure-3
- 366. Simple Jam-3
- 367. Synthethix-3
- 368. Feel-3
- 369. Accelerate-3
- 370. Beach Night-3
- 371. Irish-3
- 372. Tarantella-3
- 373. Bigband-3
- 374. Dandut-3
- 375. Fusion-3
- 376. Horse-3
- 377. Keron-3
- 378. Latin-3
- 379. Mambo-3
- 380. New Age-3
- 381. Slow RC-3
- 382. Soul-3
- 383. Twist-3
- 384. Beguine Swing-4
- 385. Beguine 1-4
- 386. Beguine 2-4
- 387. Pophit-4
- 388. Pop-4
- 389. Popmalay-4
- 390. Bossanova-4
- 391. Disco 1-4
- 392. Disco 2-4
- 393. Bluegrass Disco-4
- 394. Waltz 1-4
- 395. Waltz 2
- 396. True Ballad Waltz-4
- 397. Bossa Waltz-4
- 398. Easy Waltz-4
- 399. Shuffle Waltz-4
- 400. Reggae Waltz-4
- 401. Rhumba Waltz-4
- 402. March 1-4
- 403. March 2-4
- 404. Rhumba 1-4
- 405. Rhumba 2-4
- 406. Slow 1-4
- 407. Slow 2-4
- 408. Discocha-4
- 409. Guaracha-4
- 410. Charl-4
- 411. Samba 1-4
- 412. Samba 2-4
- 413. Ubrminimal-4
- 414. 18 Bit-4
- 415. 28 Bit-4
- 416. 16 Bit 1-4
- 417. 16 Bit 2-4
- 418. Ballad 16T-4
- 419. Country 16T-4
- 420. Tango 1-4
- 421. Tango 2-4
- 422. Polka 1-4
- 423. Polka 2-4
- 424. Pop Swing-4
- 425. Easy Swing-4
- 426. Soft Swing-4
- 427. Rock 1-4
- 428. Rock 2-4
- 429. Rock 3-4
- 430. Airy Rock-4
- 431. Heat Rock-4
- 432. Rock & Roll-4
- 433. Urban-4
- 434. Ballad-4
- 435. Jazz Ballad-4
- 436. C. Ballad-4
- 437. J. Ballad-4
- 438. 60 Slow Ballad-4
- 439. Piano Ballad-4
- 440. 50 Slow Ballad-4
- 441. Snakebase-4
- 442. Happy Blues-4
- 443. Old Blues-4
- 444. Bluegrass-4
- 445. Boogie 1-4
- 446. Boogie 2-4
- 447. Boogie 3-4
- 448. Shuffle 1-4
- 449. Shuffle 2-4
- 450. Dream Shuffle-4
- 451. Country Shuffle-4
- 452. Quick Shuffle-4
- 453. Reggae Shuffle-4
- 454. R&B-4
- 455. Reggae 1-4
- 456. Reggae 2-4
- 457. Reggae 3-4
- 458. Salsa 1-4
- 459. Salsa 2-4
- 460. Salsa 3-4
- 461. Techno 1-4
- 462. Techno 2-4
- 463. Funky 1-4
- 464. Funky 2-4
- 465. Dixie 1-4
- 466. Dixie 2-4
- 467. Foxtrot 1-4

## RHYTHMS

- 468. Foxtrot 2-4
- 469. R. Roll 1-4
- 470. R. Roll 2-4
- 471. Fastbeat-4
- 472. Quickbeat-4
- 473. Smooth Beat-4
- 474. Square Beat-4
- 475. Euro Beat-4
- 476. Alphadance-4
- 477. Betadance-4
- 478. Dreamdance-4
- 479. Dance 1-4
- 480. Dance 2-4
- 481. Dance 3-4
- 482. Rap-4
- 483. The Village-4
- 484. Country Shuffle-4
- 485. Electric Keys-4
- 486. Dark Keys-4
- 487. Easy Walk-4
- 488. Destiny-4
- 489. Comedy-4
- 490. Drive-4
- 491. Liquid Nova-4
- 492. Industrial Folk-4
- 493. Slow Pure-4
- 494. Simple Jam-4
- 495. Synthethix-4
- 496. Feel-4
- 497. Accelerate-4
- 498. Beach Night-4
- 499. Irish-4
- 500. Tarantella-4
- 501. Bigband-4
- 502. Dandut-4
- 503. Fusion-4
- 504. Horse-4
- 505. Keron-4
- 506. Latin-4
- 507. Mambo-4
- 508. New Age-4
- 509. Slow RC-4
- 510. Soul-4
- 511. Twist-4
- 512. Beguine Swing-5
- 513. Beguine 1-5
- 514. Beguine 2-5
- 515. Pophit-5
- 516. Pop-5
- 517. Popmalay-5
- 518. Bossanova-5
- 519. Disco 1-5
- 520. Disco 2-5
- 521. Bluegrass Disco-5
- 522. Waltz 1-5
- 523. Waltz 2
- 524. True Ballad Waltz-5
- 525. Bossa Waltz-5
- 526. Easy Waltz-5
- 527. Shuffle Waltz-5
- 528. Reggae Waltz-5
- 529. Rhumba Waltz-5
- 530. March 1-5
- 531. March 2-5
- 532. Rhumba 1-5
- 533. Rhumba 2-5
- 534. Slow 1-5
- 535. Slow 2-5
- 536. Discocha-5
- 537. Guaracha-5
- 538. Charl-5
- 539. Samba 1-5
- 540. Samba 2-5
- 541. Ubminimal-5
- 542. 18 Bit-5
- 543. 28 Bit-5
- 544. 16 Bit 1-5
- 545. 16 Bit 2-5
- 546. Ballad 16T-5
- 547. Country 16T-5
- 548. Tango 1-5
- 549. Tango 2-5
- 550. Polka 1-5
- 551. Polka 2-5
- 552. Pop Swing-5
- 553. Easy Swing-5
- 554. Soft Swing-5
- 555. Rock 1-5
- 556. Rock 2-5
- 557. Rock 3-5
- 558. Airy Rock-5
- 559. Heat Rock-5
- 560. Rock & Roll-5
- 561. Urban-5
- 562. Ballad-5
- 563. Jazz Ballad-5
- 564. C. Ballad-5
- 565. J. Ballad-5
- 566. 60 Slow Ballad-5
- 567. Piano Ballad-5
- 568. 50 Slow Ballad-5
- 569. Snakebase-5
- 570. Happy Blues-5
- 571. Old Blues-5
- 572. Bluegrass-5
- 573. Boogie 1-5
- 574. Boogie 2-5
- 575. Boogie 3-5
- 576. Shuffle 1-5
- 577. Shuffle 2-5
- 578. Dream Shuffle-5
- 579. Country Shuffle-5
- 580. Quick Shuffle-5
- 581. Reggae Shuffle-5
- 582. R&B-5
- 583. Reggae 1-5
- 584. Reggae 2-5
- 585. Reggae 3-5
- 586. Salsa 1-5
- 587. Salsa 2-5
- 588. Salsa 3-5
- 589. Techno 1-5
- 590. Techno 2-5
- 591. Funky 1-5
- 592. Funky 2-5
- 593. Dixie 1-5
- 594. Dixie 2-5
- 595. Foxtrot 1-5
- 596. Foxtrot 2-5
- 597. R. Roll 1-5
- 598. R. Roll 2-5
- 599. Fastbeat-5

## DEMO SONG LIST

0. Fur Elise
1. Turkish March
2. Greensleeves
3. Swan Lake
4. Blue Danube
5. Symphony Of Carmen
6. The Ode To Joy
7. Spring Song
8. The Entertainer
9. The Flight Of The Bumble-bee
10. Goin' Home
11. Hungarian Dance
12. Mozart Piano Sonata
13. Arabesque No.1
14. A Maiden's Prayer
15. Vienna Waltz
16. Minuet In G
17. Canon And Gigue In D Major
18. "William Tell" Overture
19. The Magic Flute-overture
20. Schubert Serenade
21. Fantasy Impromptu
22. Chopin Tristeza
23. Cuckoo Waltz
24. Minuet From Larlesienne
25. Katyusha
26. Clementi Sonata
27. Torna A Surriento
28. Valse,op.64-1
29. The Merry Widow Waltz
30. Chopin Revolution Etude
31. Gavotte
32. Czardas
33. Cinquantaine
34. Kalinka
35. The New World  
Symphony Theme
36. The Wedding March
37. Schumann Reverie
38. Humoresque
39. Brahms Lullaby
40. Ave Maria (Original Version)
41. Auld Lang Syne
42. Waltz Of The Flowers
43. Il Berhiere Di Siviglia
44. Tales From The Vienna Woods
45. Traviata
46. Csikos Post
47. Italian Polka
48. Santa Lucia
49. Johann Sebastian Bach
50. La Paloma
51. Turkey In The Straw
52. Clarinet Polka
53. American Patrol
54. Radetzky March
55. Cow Boy
56. Mozart #40
57. Old French Air
58. Red River Valley
59. Polonaise
60. Noctume Op.9-2
61. Happy Home
62. Prairie Song
63. Picnic
64. My Old Kentucky Home
65. La Cucaracha
66. The Old Gray Mare
67. She Wore A Yellow Ribbon
68. Farmer And The Dell
69. Yankee Doodle
70. Old Mcdonald Had A Farm
71. Camptown Races
72. She'll Be Coming Around The  
Mountain
73. My Bonnie Lies Over The  
Ocean
74. Home On The Range
75. Danny Boy
76. Little Brown Jug
77. Oh! Susanna
78. London Bridge
79. Happy Birthday
80. Skip To My Lou
81. This Old Man
82. Twinkle Twinkle Little Star
83. Mary Had A Little Lamb
84. Ding Dong Merrily On High
85. Bingo
86. Do Your Ears Hang Low
87. John Jacob Jingleheimer  
Schmidt
88. If You're Happy And You  
Know It
89. I've Been Working On  
The Railroad
90. It's Rainging, It's Pouring
91. Down By The Station
92. Row,row,row Your Boat
93. Nutcracker March
94. Hark The Herald Angels Sing
95. Frosty The Snowman
96. Jingle Bells
97. Silent Night
98. We Wish You A  
Merry Christmas
99. Joy To The World

# SINGLE FINGER CHORD CHART

	Major	Minor	7 <sup>th</sup>	Minor 7 <sup>th</sup>
C				
C#				
D				
D#				
E				
F				
F#				
G				
G#				
A				
A#				
B				

# CHORD CHART

	M	m	7	m7	dim7	M7	m7 <sup>-5</sup>	dim
C								
C#/(D♭)								
D								
(D#)/E♭								
E								
F								
F#/(G♭)								
G								
(G#)/A♭								
A								
(A#)/B♭								
B								

# KEYBOARD DRUM GROUP CHART

 A1	 A#1	 B1	 C2	 C#2	 L	 D#2	 H
 F2	 F#2	 G2	 LM	 HM	 A#2	 H	 C3
 C#3	 D3	 D#3	 E3	 F3	 F#3	 G3	 G#3
 A3	 A#3	 B3	 C4	 C#4	 D4	 D#4	 E4
 F4	 F#4	 G4	 G#4	 A4	 A#4	 B4	 C5
 C#5	 D5	 D#5	 E5	 F5	 F#5	 G5	 G#5
 A5	 A#5	 B5	 C6	 C#6	 D6	 D#6	 E6
 F6	 F#6	 G6	 G#6	 A6	 A#6	 B6	 C7
 C#7	 D7	 D#7	 E7	 F7	 F#7	 G7	 G#7
 LM	 HM	 B7	 C8	 C#8	 D8	 D#8	 E8
 F8	 F#8	 GB	 G#B	 A8	 A#8	 B8	 LM



# HELP CENTER



Question about your product? We're here to help. Visit us at:

[help.bestchoiceproducts.com](http://help.bestchoiceproducts.com)



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

## PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledged by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Tustin, CA 92780

## WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.