

























# ASSEMBLY INSTRUCTION

## FOLDING DESK WITH BOOKCASE

<b>A</b> Side Frame - Left	<b>B</b> Side Frame - Right	<b>C</b> Cross Bar - Shelf	<b>D</b> Cross Bar - Desk
			
1pc	1pc	3pcs	1pc
<b>E</b> Cross Bar - Bottom	<b>F</b> Support Frame	<b>G</b> Support Bar	<b>H</b> Cross Bar - Top
			
1pc	1pc	2pcs	1pc
<b>I</b> Shelf Board - Top	<b>J</b> Shelf Board - Upper	<b>K</b> Shelf Board - Middle	<b>L</b> Shelf Board - Lower
			
1pc	1pc	1pc	1pc
<b>M</b> Shelf Board - Bottom	<b>N</b> Extension Desk Board	<b>O</b> Connect Bar	<b>P</b> Metal Sheet - Left
			
1pc	1pc	1pc	1pc
<b>Q</b> Metal Sheet - Right	<b>R</b> Hinge	<b>S</b> Bolt Ø1/4"x1/2"	<b>T</b> Bolt Ø3/16"x1/2"
			
1pc	3pcs	48pcs	2pcs
<b>U</b> Screw M4x13mm	<b>V</b> Bolt Ø1/4"x1/2"	<b>W</b> Flat washer Ø1/4"x16mm	<b>X</b> Flat washer Ø1/4"x12mm
			
18pcs	4pcs	48pcs	2pcs

**Y** Allen Key  
M4




1pc

**Z** Fix Bolt  
Ø32x33MM




1pc

**AA** Screwdriver  
(Not Provided)





1pc

**AB** Anti-Tipping Kit



1set




First page and second page list all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


**Remind:**

Do not fully tighten all bolts until assembly is complete. This will help all parts to assemble properly.


- 1** Assemble Cross Bar (C, D, E & H) to Side Frame - Left (A), using Bolt (S) & Flat Washer (W) by Allen Key (Y).




- 2** Assemble Side Frame - Right (B) to Cross Bar (C, D, E & H), using Bolt (S) & Flat Washer (W) by Allen Key (Y). When assemble the Cross Bar (H), please using Bolt (S), Flat Washer (W) and the metal sheet of Anti-Tipping Kit (AB) by Allen Key (Y) in the same time.




**3** Assemble Shelf Board (I, J, L, M) to Cross Bar (C, E) and Side Frame - Left (A) & Side Frame - Right (B), using Bolt (S) & Flat Washer (W) by Allen Key (Y).




**4** Assemble Support Bar (G) to Side Frame - Left (A) & Side Frame - Right (B), using Bolt (S) & Flat Washer (W) by Allen Key (Y).




- 5** Assemble Connect Bar (O) and Hinge (R) to Extention Desk Board (N), using Bolt (T), Screw (U) & Flat Washer (X) by Screwdriver (AA).




- 6** Assemble Metal Sheet - Left (P) & Metal Sheet - Right (Q) to Support Frame (F) and Extention Desk Board (N), using Bolt (V) by Allen Key (Y). Assemble Fix Bolt (Z) to Support Frame (F), but DO NOT rotate tight.




**7** Assemble Shelf Board - Middle (K) with Extension Desk Board (N) by Hinge (R), then using Screw (U) to lock by Screwdriver (AA) as below shown.




**8** Assemble Shelf Board - Middle (K) to Side Frame - Left (A), Side Frame - Right (B) and Cross Bar - Desk (D), using Bolt (S) & Flat Washer (W) by Allen Key (Y).



- 9** Remark: When you want to unfold the extension Desk, you can align the Connect Bar (O) to Fix Bolt (Z), adjust the Fix Bolt (Z) until the Desk stabilized.



- 10** Remark: there is a Anti-Tipping Kit (AB) provided on the back of this product. Please read the instruction thoroughly and install immediately when placed in home. To prevent tip over, the product must be attached to the wall.



### **Cleaning & Care**

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.