


INSTRUCTION MANUAL



Outdoor Dining Arm Chair


V1.0

! NOTICE


Do not overtighten screws. (Insert all screws before tightening screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- When using an electric drill, please adjust its speed slowly to avoid screw slippage.

TOOLS REQUIRED




HARDWARE




PARTS


A CHAIR SEAT




B CHAIR BACK



C RIGHT CHAIR LEG




D LEFT CHAIR LEG



PRODUCT ASSEMBLY – OVERALL VIEW


Look at the overall view of this chair and learn the exact position of each part to be assembled.



PRODUCT ASSEMBLY


1

Attach **Part C Right Chair Leg** and **Part D Left Chair Leg** to **Part A Chair Seat** with 4 pcs of **Hardware #1 Screw**.



2


Attach **Part C Right Chair Leg** and **Part D Left Chair Leg** to **Part A Chair Seat** with 4 pcs of **Hardware #1 Screw**.



PRODUCT ASSEMBLY

3


Attach **Part C Right Chair Leg** and **Part D Left Chair Leg** to **Part B Chair Back** with 4 pcs of **Hardware #2 Bolt**.



4

Insert the **Hardware #3 Poly Cap** into the exposed bolt holes on the backrest and the chair legs until they are flush with the surface. Use a rubber mallet to help with the process if needed.

CAUTION: These poly caps are designed for a permanent fit and are very difficult to remove once installed. If you anticipate needing to disassemble the chair (for moving or storage) in the future, you may choose to leave these caps off.



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.