

SAFETY INFORMATION

Released Date: 2026-05-13

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.
- Use ONLY LED bulbs in this fixture. Incandescent and halogen lamps may cause severe thermal damage.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED




CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.

PACKAGE CONTENTS




A Ceiling Canopy
x 1



B Shade
x 1

MOUNTING HARDWARE



AA Crossbar Assembly
x 1



BB Wire Connector
x 3




CC Outlet Box Screw
x 2

INSTALLATION

1


Install Crossbar Assembly



Outlet Box

2

Wiring



White wire from supply White from fixture


Black (or red) wire from supply Black from fixture

Ground wire from supply Ground wire from fixture

Green ground screw

3

Install Ceiling Canopy to Crossbar Assembly



4

Install Bulbs

Install three correct bulbs referring to fixture markings and/or labels for maximum wattage.

Recommended Bulb Type (not included):




BULB BASE TYPE
Medium (E26)




15W
MAX

BULB TYPE
TYPE A
LED ONLY



5

Install Shade



Your installation is now complete! Restore electricity and save this sheet for future reference.