



BEST CHOICE
PRODUCTS



INSTRUCTION MANUAL

Kids 3-Piece Bistro Set
with Umbrella

⚠ WARNING
ADULT ASSEMBLY REQUIRED



110 LBS
CAPACITY
(TABLE)



70 LBS
CAPACITY
(PER CHAIR)



3-6 YEARS
OLD



1 PERSON
ASSEMBLY









UP TO 10 MIN.
ASSEMBLY

⚠ NOTICE | Please retain these instructions for future reference.

- This product requires adult assembly and supervision when in use.
- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- To wipe down item, use a damp cloth. Then, wipe it down once more with a dry cloth.
- This product is intended for residential use only.


PARTS



PRODUCT ASSEMBLY


1

Carefully unfold two **part F chairs** until the legs and seat are fully extended.
Press the locking latch downward until it snaps securely into place.




FOLD THE CHAIR: Lift the locking latch upward to disengage the lock.

While holding the latch, gently bring the legs together to fold the chair closed.




2

Slide the **part B** legs into **part C** legs.




3


Place the **part A tabletop** face down onto a flat, covered surface to prevent damage to the product.
Press the assembled leg into the **part A tabletop**.



- 4 | Firmly insert the **part E umbrella** into the **part D pole** until it locks in place.




- 5 | Open the umbrella canopy.



5

Insert the umbrella into the assembled table.

Adjust the height of the umbrella and arrange the chairs as desired.





HELP CENTER

Question about your product? We're here to help. Visit us at:

bestchoiceproducts.com/pages/help



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.