


# ASSEMBLY INSTRUCTION

## E773-04(N1) TRUNK END TABLE

**A** Table Top



1pc

**B** Leg



4pcs

**C** Bolt  
Ø1/4" x 2"



4pcs

**D** Lock Washer  
Ø1/4"



4pcs

**E** Flat Washer  
Ø1/4" x 5/8"




4pcs

**F** Allen Key  
M4




1pc



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

- 
- 1** Assembly the Leg (B) onto the Table Top (A) using Bolt (C), Lock Washer (D) and Flat Washer (E), then tighten by Allen Key (F).



---

### **Cleaning & Care**

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.