

REPLACEMENT PARTS LIST FOR MODELS "M137", "N137", "D137", "E137", "H137", "I137", "J137", "F137", "G137"
 See page 3 for illustration.

		MODELS:		M137-D	N137-D	D137-D	E137-D	H137-D	I137-D	J137-D	F137-D	G137-D
REF. NO.	DESCRIPTION	QTY	NOTES	05/18 thru 04/18	05/18 thru Current	01/19 thru Current	01/19 thru Current	02/19 thru Current	02/19 thru Current	01/19 thru Current	01/19 thru Current	02/19 thru Current
1	Case assembly - Automatic	1		004739	N/A	004739	N/A	004739	N/A	N/A	N/A	N/A
	Cover assembly - Non-Automatic	1		N/A	267051	N/A	267051	N/A	267051	267051	267051	267051
2	• Handle	1		267032	267032	267032	267032	267032	267032	267032	267032	267032
3	Case Mach. & Gasket - Automatic	1		155781	N/A	155781	N/A	155781	N/A	N/A	N/A	N/A
	Cover Mach. & Gasket - Non-Automatic	1		N/A	267052	N/A	267052	N/A	267052	267052	267052	267052
4	• Retainer - Non-Automatic	2		N/A	267053	N/A	267053	N/A	267053	267053	267053	267053
5	• Guard - Automatic	1		267008	N/A	267008	N/A	267008	N/A	N/A	N/A	N/A
6	• Gasket - Case/Cover	1		267007	267007	267007	267007	267007	267007	267007	267007	267007
7	• Arm and Seal assembly	1		004741	N/A	004741	N/A	004741	N/A	N/A	N/A	N/A
8	Switch Assembly	1		004740	N/A	004740	N/A	004740	N/A	N/A	N/A	N/A
9	Capacitor assembly	1		155782	155782	155782	155782	155782	155782	N/A	N/A	N/A
10	• Wire package	1		155783	155783	155783	155783	155783	155783	N/A	N/A	N/A
11	• Cord seal and strain relief assembly	1	4	155784	155784	155784	155784	155784	155784	155784	155784	155784
12	Cord assembly - automatic/standard	1		010925	N/A	010926	N/A	N/A	N/A	N/A	N/A	N/A
	Cord assembly - non-auto/standard	1		N/A	155785	N/A	155962	N/A	N/A	N/A	N/A	N/A
	Cord assembly - automatic/1 phase-3 wire no plug	1	5	N/A	N/A	N/A	N/A	156032	N/A	N/A	N/A	N/A
	Cord assembly - non-auto/1 phase-3 wire no plug	1	5	N/A	N/A	N/A	N/A	N/A	156033	N/A	N/A	N/A
	Cord assembly/3 phase - 4 wire no plug	1		N/A	N/A	N/A	N/A	N/A	N/A	003761	003761	003761
13	Motor housing assembly	1		155786	155786	155786	155786	155786	155786	155786	155786	155786
14	Stator with screws	1		155787	155787	155961	155961	156034	156034	156035	156036	156037
15	• Thru wall terminals	3		003402	003402	003402	003402	003402	003402	003402	003402	003402
16	• Test plugs	2		034090	034090	034090	034090	034090	034090	034090	034090	034090
17	Rotor assembly	1		155788	155788	155788	155788	155788	155788	156038	156038	156038
18	• Thrust washer	1		002140	002140	002140	002140	002140	002140	002140	002140	002140
19	• Dielectric oil	1		267056	267056	267056	267056	267056	267056	267056	267056	267056
20	• Motor housing seal	1		267006	267006	267006	267006	267006	267006	267006	267006	267006
21	Pump housing - Mach.	3		137004	137004	137004	137004	003877	003877	003877	003877	003877
22	• Shaft seal Assembly	9		267027	267027	267027	267027	267027	267027	267027	267027	267027
23	Impeller	3		137006	137006	137006	137006	137006	137006	009507	009507	009507
24	Base	2		001509	001509	001509	001509	001509	001509	001509	001509	001509
25	Float	1		034019	N/A	034019	N/A	034019	N/A	N/A	N/A	N/A
26	Float rod	1		001526	N/A	001526	N/A	001526	N/A	N/A	N/A	N/A
27	Float rod guide assembly			004676	N/A	004676	N/A	004676	N/A	N/A	N/A	N/A
28	• Screw - Case & Base (1/4-20 x 3/4" long)	9		001916	001916	001916	001916	001916	001916	001916	001916	001916
29	• Screw - Switch (#6-32 x 7/16" long)	2		004644	N/A	004644	N/A	004644	N/A	N/A	N/A	N/A
30	• Screw - Ground & Capacitor (#6-32 x 1/4" long)	1		001877	001877	001877	001877	001877	001877	001877	001877	001877
31	• Screw - Motor housing (1/4-20 x 7/8" long)	4		012491	012491	012491	012491	012491	012491	012491	012491	012491
32	• Screw - Stator (#8-32 x 3 1/16" long)	2		154768	154768	154768	154768	154768	154768	154768	154768	154768
33	• Screw - Guard & retainers/Guide (#10-24 x 3/8" long)	3		001883	001883	001883	001883	001883	001883	001883	001883	001883
34	Nut, 5/16-24 Unf SS Acorn/Low Crown	1		N/A	N/A	N/A	N/A	N/A	N/A	004348	004348	004348
*	Rebuild Kit	1		155789	155789	155789	155789	155789	155789	155789	155789	155789

Service part notes:

- 1) If an "X" follows Model No., or Date Mfg. on brass ID tag, consult factory for ordering any parts.
- 2) See FM0160 Parts Price Sheet for listing of parts prices.
- 3) "NA" indicates, not applicable.
- 4) Strain relief clamp is not sold separately, must order cord seal assembly.
- 5) Cut plug off if required.

REPLACEMENT PARTS LIST FOR MODELS “M137” and “D137”.

See page 7 for “M137” and “D137” illustration.

REF. NO.	DESCRIPTION	QTY	NOTES	MODELS:	
				M137-C	D137-C
				9/86 thru 04/18	9/86 thru Current
1	• Handle	1		267032	267032
2	Case & switch asm “130/260”	1	3	004610	004610
3	• Gasket,case/cover	1		267007	267007
4	Relay asm	1		002474	147135
5	Wire pkg	1		267014	267014
6	• Seal,thru wall term	3		003402	003402
7	• Plug,test	2		034090	034090
8	• Clamp,strain relief	1	6	NA	NA
9	Cord term & seal	1	3, 4	094071	094072
10	• Seal,cord-asm	1		094032	094032
11	Bearing,upper rotor	1		NA	NA
12	• Guard	1		267008	267008
13	Float-polypropylene	1		034019	034019
14	• Arm & seal asm “130/260”	1	3	004741	004741
15	Case & switch asm “130/260”	1	3	004739	004739
16	Switch asm “130/260”	1	3	004740	004740
□	Lead wire (gray)	1		NA	NA
17	Rod,float	1		001526	001526
18	Housing,mtr-&str regal beloit	1	1, 2	002475	002476
	Housing,mtr-& str emd			014797	008642
19	Rotor asm 115/230v/1ph regal b	1	2	267005	267005
	Rotor asm 115/230v/1ph emd			004021	004021
20	• Seal,mtr hsg	1		267006	267006
21	• Washer,trst-nyl.875x.504x.050”	1		002140	002140
22	Bearing,sleeve-lower rotor	1		NA	NA
23	Housing,pump-mach	1		137004	137004
24	• Oil,dielectric	1		267056	267056
25	Guide asm, float rod	1		004676	004676
26	• Seal asm	1		267027	267027
27	Impeller	1	4	137006	137006
28	Base & plate	1		001509	001509
29	Strainer plate	1		137008	137008
30	• Screw .25-20x.75hmm-ss	9		001916	001916
31	• Screw,#6-32x.438/Rh/pan head/	2		004644	004644
32	• Screw,#10-24 x.375 Rhm-sl ss	3		001883	001883
33	• Screw,sem/10-24 x .375 Hh-sl	2		002000	002000
34	• Screw,#6-32x.25rhmm sl tc stlgr	3		001877	001877
35	Screw,.25-20x.875”Lg hh ss/	4		012491	012491
□	Rebuild kit	1		004743	004743

• Items included in Rebuild Kit.

□ Not shown in illustration

NOTES:

- 1) Motor, housing., bearing., stator & term. (Item 18) are preassembled at the factory and must be replaced as a unit. Stator is permanently attached to the motor housing. plug (Item 7); seal, thru wall term. (Item 6) and bearing - upper (Item 11) are replaceable.
- 2) When ordering motor housing, bearing, stator and term. (Item 18) or rotor (Item 16) specify either GE or Emerson motor. GE motor can be identified by (4) half oval slots spaced at 90° around the outside diameter or the stator. Emerson motor can be identified by (2) half oval slots or holes spaced 180° around the outside diameter of the stator.
- 3) If an “X” follows model no., or date mfg. on brass ID tag, consult factory for ordering any parts.
- 4) See FM0160 parts price sheet for listing of parts prices.
- 5) “NA” indicates, not applicable.
- 6) Clamp, strain relief (Item 8) is not sold separately, must order seal, cord asm (Item 10).

REPLACEMENT PARTS LIST FOR MODEL "H137"

See page 10 for illustration.

				MODEL:	H137-C
REF. NO.	DESCRIPTION	QTY	NOTES	9/86 thru Current	
1	• Handle	1		267032	
2	Case-mach	1		004610	
3	• Gasket, case/cover	1		267007	
4	Relay asm	1		001536	
5	• Wire pkg (2) wires	1		267014	
6	• Seal, thru wall term.	3		003402	
7	• Plug, test	2		034090	
8	• Clamp, strain relief	1		001770	
9	Cord term. & Seal	1		006930	
10	• Seal, cord-asm. & Strain relief	1		094032	
11	• Guard	1		267008	
12	Float, polypropylene	1		034019	
13	• Arm & seal asm.	1		004741	
14	Case & switch asm.	1		004739	
15	Switch asm.	1		004740	
16	Rod, float-molded	1		001526	
17	Housing, mtr. & Str.	1	1, 2	003781	
18	Rotor asm.	1	2	267005	
19	• Seal mtr. Hsg.	1		267006	
20	• Washer, trst.-Nyl.	1		002140	
21	Housing, pump-mach.	1		137004	
22	• Oil, dielectric (24.5 Oz)	1		267056	
23	Guide asm., Flt. Rod	1		004676	
24	• Seal asm., Shaft	1		267027	
25	Impeller "137"	1		137006	
26	Base, mach.	1		001509	
27	• Screw, .25-20x.75 Hhm-ss	9		001916	
28	• Screw, #6-32x.438rh ph tp pe 23	2		004644	
29	• Screw, #10-24x.375rh-sl ss	3		001883	
30	• Screw, #6-32x.25rh sltc stlgr	3		001877	
31	• Screw, .25-20x.875"Lg hh ss	4		012491	
□	Rebuild kit, 3ph "137"	1		009508	

• Items included in Rebuild Kit.

□ Not shown in illustration.

NOTES:

- 1) Motor housing, bearing, stator & terminal (Item 17) are preassembled at the factory and must be replaced as a unit. Stator is permanently attached to motor housing. Plug, test (Item 7) and seal, thru wall terminal (Item 6) are replaceable.
- 2) When ordering motor housing, bearing, stator and terminal, or rotor and bearing, specify either GE or Emerson motor.
- 3) See FM0160 parts price sheet for listing of parts prices.