

Item#1919NC-6: MIRROR






This page lists all the contents included in the box. Please take time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Cleaning & Care


Treat surface with care. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

Assemble the wooden mirror support (C) to the dresser (A) with 4 pcs bolt (E), 4 pcs flat washer (F) and 4pcs spring washer (G) tighten using allen key (H).



2

Assemble the mirror (B) wooden mirror support (C) with 4pcs bolt (D), 4pcs flat washer (F) and 4pcs spring washer (G) tighten using allen key (H)



Cleaning & Care

Treat surface with care. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.