

I^{PORT} CONNECT PRO

PAYMENT PROCESSOR



72433 - CONNECT PRO PayCase AMS1

PAYMENT PROCESSOR

I PORT CONNECT PRO Payment Processor Manual

Thank you for purchasing the all-new IPORT CONNECT Platform. We hope you enjoy this revolutionary new system, and if at any time you need more assistance, please get in touch with IPORT Tech Support via Online chat or through our help desk online.

- IPORT Team

Whats in box:

- 1 - IPORT CONNECT PRO AMS1 Payment Processor Case
- 1 - Info Card
- 1- IPORT Security Tool

Glossary of Terms:


- **Payment Processor Dock** - The Finished stationary dock providing power and a mounting location for a Payment Processor Case
- **Payment Processor Case** - The removable housing providing charging and mounting for a AMS1 payment processor.

I PORT CONNECT PRO

PAYMENT PROCESSOR


I PORT CONNECT Paycase AMS1

1. Remove the AMS1 and PayCase from their packaging.



PAYMENT PROCESSOR



- 2. Slide the AMS1 into the USB-C connection at the bottom of the PayCase first, ensuring it is securely seated into the port.**



I PORT CONNECT PRO


PAYMENT PROCESSOR

3. Once the AMS1 is connected to the USB-C connector, pivot it towards the rear of the case and press firmly until it snaps into the PayCase.




PAYMENT PROCESSOR

4. The PayCase magnetically attaches to a CONNECT PRO iPad Case. The AMS1 is designed to be easily removed and attached for tap, dip, and swipe transactions.




PAYMENT PROCESSOR

5. When unlocked, the AMS1 Pro PayCase can be rotated portrait or landscape when attached to the CONNECT PRO iPad Case. Like wise, the AMS1 Case can also be locked in place onto the CONNECT PRO Case using the included IPORT Security tool.



PAYMENT PROCESSOR

6. The **CONNECT PRO AMS1 Case** can be used on the **CONNECT Pro PlayStation (72313)** to charge or operate without an iPad.



PAYMENT PROCESSOR

7. To remove the AMS1, Insert a small flat object into the top portion of the case to release the tab at the top. Once the tab is free, gently wiggle the AMS1 out of the USB-C connection.

