


ASSEMBLY AND INSTALLATION INSTRUCTIONS

T0809

WARNING: Turn off the main power at circuit breaker before installing fixture.
AVERTISSEMENT: Coupez la source d'alimentation principale au panneau central de disjoncteurs avant d'installer le luminaire.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. Read and save these instructions.


Hardware Package (included):



Installation Steps

Turn off the power at fuse or circuit box.

1. Unscrew the two set screws and remove the metal frame from the ceiling pan.
2. Remove the end cap (D) from the mounting strap unit (A).
3. Attach the mounting strap unit (A) to the outlet box by using two mounting screws (B).
4. Pull out the source wires from the outlet box. Make wire connections using wire connectors (C) as follows:
 - Connect the hot wires (black insulation) from the fixture to the black wire from the power source.
 - Connect the neutral wires (white insulation) from the fixture to the white wire from the power source.
 - Attach the fixture ground wires (bare wire) to the mounting strap unit (A) with the green ground screw, then depending on local code, connect it to the house ground wire with the wire connector (C).Carefully put all of the wires back into the outlet box.
5. Attach the ceiling pan to the mounting strap unit (A) by inserting threaded pipe into the center hole the ceiling pan and secure it with the end cap (D).
NOTE: Depth of threaded pipe may need to be adjusted to properly fit the end cap.
6. Install the bulbs (not included). See relamping label at socket area or packaging for maximum wattage allowed.





7. Place the bottom glass panel into the metal frame, and set the two "S" clips (E) each side on the slot and hold the bottom glass panel by inserting the side glass panels inside the metal frame. Then press the top clips on the fixture to secure the side glass panels.

8. Attach the metal frame to the ceiling pan by using two set screws.

Turn on the power at fuse or circuit box.

The following parts are available for reorder if damaged or missing.

Spare Parts List:



A: 4-1/2"

B: 12"

1 Year Warranty

Vaxcel warrants all of our products against defects in workmanship and finishes for one year following the date of shipment.

Exclusions: This warranty does not include the failure of products from extreme acts of nature; environmental conditions not suited for the products intended use; operation in temperatures outside of the range specified in the instruction manual; usage with improper power supply, power surges or dips. For coastal locations, some corrosion is considered normal for the environment.

Vaxcel reserves the right to repair, replace or issue a credit for any properly installed product, provided it is returned per RMA instruction. This warranty is limited to the cost of the product only and does not extend to transportation, installation or replacement costs.

How can warranty service be obtained?

info@vaxcel.com

1-800-482-9235