

MONET SOFA

Thank you for choosing this quality product. Be sure to check all packaging materials carefully for small parts that may have become loose during shipment and place all parts on a non-abrasive surface.

IMPORTANT: These parts can be cumbersome and heavy to some people, therefore the assistance of two or more people is recommended in order to prevent personal injury and insure the furniture is not damaged during the assembly Process.

PART LIST

- A. [1] SOFA
- B. [2] LEGS

INSTRUCTIONS

- 1. Lay the sofa (A) on a flat surface.
- 2. Attach the leg (B) to the sofa (A). Align and insert Allen bolt (1) together with lock washer (2) and flat washer (3), Tighten all the bolts by using Allen wrench (4). See **FIGURE 01**.
- 3. Turn the sofa into upright position.
- 4. Assembly is complete.

HARDWARE LIST

NO	DESCRIPTION		QTY
1		ALLEN BOLT	12
2	0	LOCK WASHER	12
3	0	FLAT WASHER	12
4		ALLEN WRENCH	1

